


DF30-C-MD-TCP

User manual



1 Preface

■ Introduction

The DF30-C-MD-TCP communication interface module (hereinafter referred to as this module) is connected to the Modbus/TCP network as a Modbus/TCP slave station, and can be expanded through this module to expand local modules such as digital, analog, temperature, pulse, and communication gateway.

This manual explains the basic information of the product, electrical installation, programming examples, mechanical installation, etc.

■ Meet the standards

Please refer to the table below for relevant certification categories, directives and standards.

Certification Name	Instruction Name		Meet the standards
CE certified	EMC directive	2014/30/EU	EN 61131-2
	LVD instructions	2014/35/EU	EN 61010-1 EN 61010-2-201
	RoHS Directive	2011/65/EU amended by (EU) 2015/863	EN IEC 63000

■ More information

■ Version change history

Revision date	Release version	Changes
2025-02-28	2025-2-28	The manual was published for the first time

■ Warranty Statement

Under normal use, if the product fails or is damaged, we will provide warranty service within the warranty period (please refer to the order form for details of the product warranty period). If the warranty period is exceeded, the repair fee will be charged.

During the warranty period, repair fees will be charged for product damage caused by the following situations.

- Failure to operate this product as specified in the manual results in product damage.
- Product damage caused by fire, water damage, abnormal voltage.
- Use this product for abnormal functions, causing product damage.
- Product damage caused by exceeding the scope of use specified by the product.
- Secondary damage to products caused by force majeure (natural disasters, earthquakes, lightning strikes)..

The relevant service fees are calculated according to the manufacturer's unified standards, and if there is a contract, it will be dealt with on the principle of contract priority.

For detailed warranty descriptions, please refer to the Product Warranty Card.

2 Safety precautions

■ Safety Statement

➤ This chapter describes the safety precautions that need to be taken into account when using this product. Before using this product, please read the instruction manual and properly understand the relevant information on safety precautions. Failure to comply with the matters agreed in the safety precautions may result in death, serious injury, or damage to the equipment.

➤ The "hazards", "warnings" and "precautions" in the manual do not represent all safety matters to be observed and are only in addition to all safety precautions.

➤ This product should be used in an environment that meets the requirements of the design specifications, otherwise it may cause failure, and abnormal functions or damage to parts caused by non-compliance with relevant regulations are not within the scope of product quality assurance.

➤ The company will not bear any legal responsibility for personal safety accidents or property damage caused by non-compliance with the content of this book or illegal operation of products.

■ Security level definition

Danger:

Indicates that if not done as prescribed, it will result in death or serious bodily harm.

Warning:

Indicates that failure to do so may result in death or serious bodily harm.

Attention:

Indicates that if not done as prescribed, it may result in minor bodily injury or damage to the equipment.

■ Safety precautions

➤ The illustration of the product in this instruction manual, sometimes to show the details of the product, is the state of the product with the outer cover or safety cover

removed. When using this product, be sure to install the cover or cover according to the regulations and operate according to the instructions in the instruction manual.

➤ The product illustrations in this manual are examples only and may differ slightly from the products you ordered, please refer to the actual products ordered.

➤ Operators must take mechanical protective measures to protect personal safety, please wear and wear necessary protective equipment, such as wearing anti-smashing shoes, safety clothing, safety goggles, protective gloves and sleeves, etc.

Unboxing and acceptance

Attention:

- When unpacking, you will find that the product and product accessories are damaged, rusted, signs of use and other problems, please do not install!
- Do not install if you find water inside the product when you open the box, missing parts, or damaged parts!
- Please check the packing list carefully, if you find that the packing list does not match the product name, do not install it!
- Before unpacking, please check whether the outer packaging of the equipment is intact, whether it is damaged, soaked, damp, deformed, etc.
- Please open the package in the order of layers, it is strictly forbidden to beat violently!
- When unpacking, please check whether there is any damage, rust, bruises, etc. on the surface of the equipment and accessories.
- After unpacking, please carefully check the packing list and check whether the equipment and accessories are complete.

Storage and transportation

Attention:

- When handling the product, be sure to lift it gently and always pay attention to the objects under your feet to prevent tripping or falling, otherwise there is a risk of injury or product damage!
- When handling the product with your bare hands, be sure to hold on to the product shell to avoid the product parts falling, otherwise there is a risk of injury!

- Please store and transport in strict accordance with the storage and transportation conditions required by the product, otherwise there is a risk of damage to the product.
- Avoid storage and transportation in places such as water splashes and rain, direct sunlight, strong electric fields, strong magnetic fields, and strong vibrations.
- Avoid storing the product for more than 3 months, and if the storage time is too long, please carry out stricter protection and necessary inspections.
- Please pack the product tightly before transporting it by vehicle, and use a closed box for long-distance transportation.
- It is strictly forbidden to transport this product in mixed packaging with equipment or items that may affect or damage this product.

When installing

Danger: 是

- Only professionals with electrical knowledge who have been trained in electrical equipment can operate it. Non-professional operation is strictly prohibited!

Warning:

- Be sure to read the product instruction manual carefully and safety precautions before installation!
- Do not install this product in places with strong electric fields or strong electromagnetic interference!
- Before proceeding with the installation work, ensure that the installation location is mechanically strong enough to support the weight of the equipment, otherwise it will lead to mechanical hazards.
- When performing installation work, do not wear loose clothes or accessories, otherwise there may be a risk of electric shock!
- When installing the product in an enclosed environment (such as inside a cabinet or chassis), cool it adequately with a cooling device (such as a cooling fan or cooling air conditioner) to meet the installation environment requirements, which may cause the product to overheat or fire.
- Modification of this product is strictly prohibited!

- When this product is installed in a cabinet or terminal equipment, the cabinet or terminal equipment needs to provide corresponding protective devices such as fireproof enclosures, electrical protective enclosures, and mechanical protective enclosures, and the protection level should comply with relevant IEC standards and local laws and regulations.
- When it is necessary to install equipment with strong electromagnetic wave interference such as transformers, please install a shielding protection device to avoid malfunctions of this product!
- Please install the product on metal and other flame-retardant objects, and do not let flammable materials touch the product or attach flammable materials to the product, otherwise there is a risk of fire.

Attention:


- When installing the product, cover the top of the product with a cloth or paper to prevent foreign objects such as metal shavings, oil, and water from entering the product during drilling and causing product failure. After the operation, please remove the cover to avoid the cover blocking the ventilation hole and affecting heat dissipation, causing the product to heat abnormally.
- Resonance can occur when variable speed operation is performed on machinery running at a constant speed. In this case, installing anti-vibration rubber under the motor frame or using a vibration suppression function can effectively reduce resonance.

When wiring**Danger:**

- Non-professionals are strictly prohibited from equipment installation, wiring, maintenance, inspection or component replacement!
- Before wiring, disconnect all equipment. After cutting off the power supply, there is residual voltage in the internal capacitor of the device, please wait for at least the time specified on the warning label of the product before wiring and other operations. Measure the DC voltage of the main loop and confirm that it is below the safe voltage, otherwise there will be a risk of electric shock.
- Please disconnect the wiring, remove the product cover, or touch the circuit board while

the power supply is cut off, as there is a risk of electric shock.

● Be sure to ensure good grounding of the equipment and products, otherwise there is a risk of electric shock. Grounding should be done separately or single-point grounding, and public grounding should not be used.



Warning:

- It is strictly forbidden to connect the input power supply to the output of the device or product, otherwise it will cause damage to the equipment or even cause a fire.
- When connecting the drive equipment with the motor, be sure to ensure that the product and the motor terminals are in the correct sequence to avoid reverse rotation of the motor.
- The cables used during wiring must meet the corresponding wire diameter and shielding requirements, and the shielding layer of shielded cables needs to be reliably grounded at one end!
- Once the wiring is complete, ensure that all cables are wired correctly and that there are no falling screws, spacers, or exposed cables inside the product, otherwise there may be a risk of electric shock or damage to the product.

Attention:

- Follow the steps specified in the ESD and wear an electrostatic bracelet for wiring and other operations to avoid damaging the electrical circuits inside the device or product.
- When wiring the control loop, use a double-stranded shielding wire to connect the shield to the grounding terminal of the product for grounding, otherwise it will cause the product to act abnormally.

When powering up

Danger:

- Before powering on, make sure the product is properly installed, the wiring is secure, and the motor unit allows for restarting.

- Before powering on, please make sure that the power supply meets the product requirements to avoid causing product damage or fire!
- It is strictly forbidden to open the product cabinet door or product protective cover in the state of power, touch any terminal block of the product, or disassemble any device or part of the product, otherwise there is a risk of electric shock!

Warning:

- After the wiring operation and parameter setting are completed, please conduct a test run of the machine to confirm that the machine can operate safely, otherwise it may cause injury to personnel or damage to the equipment.
- Before powering on, make sure that the rated voltage of the product is the same as the power supply voltage. If the power supply voltage is used incorrectly, there is a risk of fire.
- Before powering on, make sure that there are no people around the product, motor and machinery, otherwise it may cause injury or death.

Runtime**Danger :**

- It is strictly forbidden for non-professionals to operate the product, otherwise there is a risk of injury or death!
- It is strictly forbidden to touch any terminal block of the equipment and disassemble any device or part of the product in the operating state, otherwise there is a risk of electric shock!

Warning:

- It is strictly forbidden to touch the device shell, fan or resistor to test the temperature, otherwise it may cause burns!
- During operation, avoid other items or metal objects falling into the equipment, otherwise it may cause fire or product damage!

Maintenance**Danger :**

- Non-professionals are strictly prohibited from equipment installation, wiring, maintenance, inspection or component replacement!
- It is strictly forbidden to maintain the equipment in the state of power, otherwise there is a risk of electric shock!
- After cutting off the power to all devices, wait at least for the time specified on the warning label on the product before performing equipment maintenance.
- When using a PM motor, an induced voltage is generated on the motor terminals during motor rotation even if the power to the product is turned off. Do not touch the motor terminals, otherwise there may be a risk of electric shock.

Warning:

- Please conduct daily and regular inspections and maintenance of equipment and products in accordance with equipment maintenance and maintenance requirements, and make maintenance records.

When repairing**Danger:**

- Non-professionals are strictly prohibited from equipment installation, wiring, maintenance, inspection or component replacement!
- It is strictly forbidden to carry out equipment maintenance in the state of power, otherwise there is a risk of electric shock!
- After cutting off the power to all equipment, please wait at least the time specified on the warning label on the product before performing equipment inspection, repair, etc. operations.

Warning:

- Please report the equipment in accordance with the product warranty agreement.
- When a fuse blows, a circuit breaker trips, or a leakage current circuit breaker (ELCB) trips, wait at least for the time specified on the warning label on the product before turning on the power supply or operating the machine, as this may result in casualties and damage to the equipment.
- When the equipment fails or is damaged, professionals must troubleshoot and repair the

equipment and products according to the maintenance guidance, and make maintenance records.

- Please follow the product wearing parts replacement instructions for replacement.
- Do not continue to use machines that have already been damaged, as this may result in death or death or greater damage to the product.
- After replacing the equipment, be sure to check the wiring and set the parameters again.

报废时

Warning:

- Please scrap equipment and products in accordance with relevant national regulations and standards to avoid property damage or casualties!
- Scrapped equipment and products should be disposed of and recycled in accordance with industrial waste treatment standards to avoid polluting the environment.

■ Safety signage

In order to ensure safe operation, please be sure to abide by the safety signs pasted on the equipment, and do not damage or peel off the safety signs. The safety mark description is as follows:

Safety signage	Content description
	Please read the safety manual and instructions carefully before using the product, otherwise there is a risk of injury or death or damage to the product!

3 Product information


3.1 Model and nameplate description

■ Nameplate description



3.2 Part description

Light				
	LED No	Status and Meaning	LED No	Status and Meaning
	PWR	Green: The system power supply is normal	RUN	Green: It is in a normal communication state
		Green extinguishing: The system power supply is abnormal		Green extinguishing: in the initial state
	SF	Red: The device is in forced operation mode (reservation, BootLoad mode, etc.)		

		Flashing (red): Configuration error, coupler error, module error, new diagnostic information, etc
		Red extinguishing: The equipment is normal
	ERR	Red light: This product is disconnected
		Flashing (red): The expansion module configuration is inconsistent
		Red extinguishing: No communication failure
Terminal blocks		
Interface name	Functional definition	
PORT1	Modbus/TCP Ethernet interface	
PORT2	Modbus/TCP Ethernet interface	
24V power supply	Module power input terminals	
Type-C interface	Used for single board software upgrade port	
DIP switch		
		
Functional definition	The position dialed to ON is valid, each representing 1, 2, 4, 8, 16, 32, 64, 128 in turn Used to set the D segment of the adapter IP address A:B:C:D	
1~253	Dial value 1~253: The last segment of the corresponding IP address A:B:C:1~253	
254	Dial value 254: Reset the IP address 192.168.1.254	
0 or 255	Segments A:B:C:D all use the IP information stored by the web page configuration	
Factory default IP	Web page configuration save: 192.168.1.254 Dial the DIP switch to 0 The IP address is configured to 192.168.1254	


3.3 Specifications

Structural parameters	
Dimensions (WxHxD)	24mm x 104mm x 80mm
Weight	103.4g
Power Parameters	
The terminal input power supply is rated voltage	24V DC (20.4V DC~ 28.8V DC)
The terminal input power supply is rated current	5A (typical at 24V DC)
The USYS backplane outputs the power supply voltage rating	5V DC (4.75V DC~5.25V DC)
The Usys backplane outputs the current rating	2A (typical at 5V)
UIN backplane output power supply rated voltage	24V DC (20.4V DC~ 28.8V DC)
The UIN backplane outputs the power supply current rating	4A (typical at 24V)
Functional parameters	
Specifications	Modbus/TCP bus, 2 RJ45, expandable 32 modules, 24VDC
Communication interface	2 RJ45 interfaces with integrated switch function
Network topology	Modbus/TCP
Communication protocols	10/100Mbps, full duplex
Communication rate	Modbus/TCP specification
Bus address settings	100 meters
Address mapping	Standard and enhanced diagnosis
Diagnosis	Electrical isolation from the site
Isolation method	Class 5 twisted pairs


Transmission medium	Modbus/TCP bus, 2 RJ45, expandable 32 modules, 24VDC
Software parameters	
IP ADDRESS ALLOCATION	static IP allocation (software configuration via web page, hardware DIP switch configuration), Support reset to default address (192.168.1.254)
Port number	502 (Modbus TCP standard port).
Web configuration	Configure parameters via web pages
Number of client connections	Support 7
The total amount of input and output data	Maximum 10,000 bytes
Function code support	01/02/03/04/05/06/15/16
Firmware upgrade method	BootLoader mode upgrade, serial port (UART) interface, YMODEM protocol
Wiring parameters	
Connection technology: communication/fieldbus	Modbus/TCP IO: 2 x RJ-45
Connectivity technology	PUSH-IN type terminal blocks
Connection type	System/field power/input
Crimping area of the wire	0.34~1.5mm ²
Stripping length	10mm
Installation method:	DIN-35 TYPE RAIL
Material parameters	
Color	Pantone 419C
Shell material	PC PLASTIC
Environmental requirements	
Allowable ambient temperature (during operation)	-20~55°C
Allowable ambient	-40~85°C

temperature (storage)	
Types of protection	IP20
Contamination level	2. Comply with IEC 61131-2 standard
Working altitude	0~2000m
Relative humidity (non-condensing)	5~95%RH
Anti-vibration	1g, in accordance with IEC 60068-2-6 standard
Impact resistance	15g, in accordance with IEC 60068-2-27
EMC ANTI-INTERFERENCE RATING	Zone B, IEC61131-2
Corrosion resistance	Compliant with IEC 60068-2-42 and IEC 60068-2-43 standards

3.4 Wiring schematic




3.5 System block diagram




3.6 Installation and disassembly

3.6.1 Mounting dimensions


➤ The mounting dimension information is shown in millimeters (mm) as shown in the figure below. .



- Connect the cables




- tail cover




3.6.2 Installation guide

- The inter-module assembly is sliding to install via the top and bottom rails of the module, as shown in the figure below.



➤ When installing, align the module with the DIN rail, press the module in the direction indicated by the arrow, and there will be a noticeable clamping sound after installation, as shown in the figure below.



➤ Confirm that the DIN rail lock of the module is locked, and the locking and unlocking status of the rail lock are shown in the figure below.



If the DIN rail latch is below, it is locked.


If the DIN rail latch is on top, it is unlocked.

When unlocked, press down on the DIN rail latch to bring it locked.

➤ The tail cover needs to be installed on the last module to prevent the metal PIN from being exposed, and a DIN rail clip is installed at both ends of the main unit or module to prevent the module from sliding left and right, as shown in the figure below.


➤ When installing the guide rail clip, hook the bottom of the guide rail clip to the bottom of the guide rail and turn the guide rail clip to make the guide rail clip

➤ The upper end hooks the upper end of the rail, and finally the fastening screw locks the guide rail snap.



3.6.3 Disassembly method:

➤ Use a flathead screwdriver or similar tool to pry the rail latch upwards, then pull the module away from the DIN rail and press down on the top of the latch when finished



3.6.4 Notes:

- Before installing or disassembling the module, make sure the module is powered off.
- If you encounter a module that is difficult to install, do not use brute force to install it to avoid damaging the current module or other modules. The module should be disassembled from the rail, checked for abnormalities (such as foreign body blockage, etc.), and confirmed that there was no problem before plugging and unplugging.
- When this product is installed on a non-standard DIN rail (DIN rail thickness is 1.0mm), it will cause the DIN rail lock to fail, and the product will not be installed in place, resulting in the product not working normally.


4 Module description:

Installation instructions:


Size description


➤ The mounting dimension information is shown in millimeters (mm) as shown in the figure below.

■ 16-bit module




■ 32-bit module






Connect the cables

■ 16-bit module




■ 32-bit module




Installation guide

The inter-module assembly is sliding to install via the top and bottom rails of the module, as shown in the figure below.




- When installing, align the module with the DIN rail, press the module in the direction

indicated by the arrow, and there will be a noticeable clamping sound after installation, as shown in the figure below.



➤ Confirm that the DIN rail lock of the module is locked, and the locking and unlocking status of the rail lock are shown in the figure below.




If the DIN rail latch is below, it is locked.

If the DIN rail latch is on top, it is unlocked.

When unlocked, press down on the DIN rail latch to bring it locked.


➤ The tail cover needs to be installed on the last module to prevent the metal PIN from being exposed, and a DIN rail clip is installed at both ends of the main unit or module to prevent the module from sliding left and right, as shown in the figure below.

➤ When installing the guide rail clip, hook the bottom of the guide rail clip to the bottom of the guide rail and turn the guide rail clip so that the upper end of the guide rail clip hooks the upper end of the guide rail, and finally tighten the screw to lock the guide rail clip.



Disassembly method:

Use a flathead screwdriver or similar tool to pry the rail latch upwards, then pull the module away from the DIN rail and press down on the top of the latch when finished



Notes:


- Before installing or disassembling the module, make sure the module is powered off.
- If you encounter a module that is difficult to install, do not use brute force to install it to avoid damaging the current module or other modules. The module should be

disassembled from the rail, checked for abnormalities (such as foreign body blockage, etc.), and confirmed that there was no problem before plugging and unplugging.

➤ When this product is installed on a non-standard DIN rail (DIN rail thickness is 1.0mm), it will cause the DIN rail lock to fail, and the product will not be installed in place, resulting in the product not working normally.

4.1 DF30-M-16DI-P/N

4.1.1 Part description

Light						
	LED No	Status and Meaning	LED No	Status and Meaning		
	PWR	Green: The system power supply is normal	RUN	Green: The module is running normally		
		Green extinguishing: The system power supply is abnormal		Green extinguishing: module hardware failure, communication failure		
				Green flashing: Configuration failure/failsafe mode		
	LED1-1	Green Bright: Channel 1-16 input signal is valid.				
	6	Green off: Channel 1-16 input signal invalid				
Terminal block						
Serial number	Signal	illustrate	Serial number	Signal	illustrate	
A1	DI 1	Digital input channel1	B1	DI 9	Digital input channel9	
A2	DI 2	Digital input channel2	B2	DI 10	Digital input channel10	
A3	DI 3	Digital input channel3	B3	DI 11	Digital input channel11	
A4	DI 4	Digital input channel4	B4	DI 12	Digital input channel12	
A5	DI 5	Digital input channel5	B5	DI 13	Digital input channel13	
A6	DI 6	Digital input channel6	B6	DI 14	Digital input channel14	

A7	DI 7	Digital input channel7	B7	DI 15	Digital input channel15
A8	DI 8	Digital input channel8	B8	DI 16	Digital input channel16
A9	COM	Public end pin	B9	COM	Public end pin


4.1.2 Specifications

Structural parameters		
Dimensions (WxHxD)		12mm x 100mm x 80mm
Weight		71.5g
Power Parameters		
The rated voltage of the USYS bus input power supply		5V DC +20%/−15% (4.25V DC~ 6V DC)
The USYS bus input power supply is rated current		<50mA (typical at 5V DC)
UOUT power supply input rated voltage		24 V DC +20%/−15% (20.4V DC~28.8V DC)
UOUT power supply input current rating		<4A (typical at 24V DC)
UOUT power input anti-reverse plug protection		Yes
The module prevents the spread of power failures		Yes
Functional parameters		
Module type		Numeric input
Number of channels		16
Signal type		PNP&NPN
Connection type		1- Wire system
Signal type	"ON" signal voltage	Differential pressure > 11VDC (differential pressure from common input)

	"OFF" signal voltage	Differential pressure < 5VDC (differential pressure from common input)
Input impedance		>7.5kΩ
Hardware response time		100us/100us
Whether to quarantine		Yes
Light status		When the input is in the drive state, the input Light is on (software control)
Software parameters		
Data size		2 Byte
Filter time configuration		Supports single-channel independent configuration
Sync mode		Synchronization within the same coupler group is supported
I/O mapping		Support bit-by-bit, byte-by-byte, and word-by-word mapping
Wiring parameters		
Connectivity technology		PUSH-IN type terminal blocks
Connection type		System/field power/input
Crimping area of the wire		0.34~1.5mm
Stripping length		10mm
Installation method:		DIN-35 TYPE RAIL
Material parameters		
Color		Pantone 419C
Shell material		PC PLASTIC
Environmental requirements		
Allowable ambient temperature (during operation)		-20~55°C
Allowable ambient temperature (storage)		-40~85°C
Types of protection		IP20
Contamination level		2. Comply with IEC 61131-2 standard

Working altitude	0~2000m
Relative humidity (non-condensing)	5~95%RH
Anti-vibration	1g, in accordance with IEC 60068-2-6 standard
Impact resistance	15g, in accordance with IEC 60068-2-27
EMC ANTI-INTERFERENCE RATING	Zone B, IEC61131-2
Corrosion resistance	Compliant with IEC 60068-2-42 and IEC 60068-2-43 standards

4.1.3 Wiring diagram



4.2 DF30-M-32DI-P/N

4.2.1Part description

Light

32DI P R 1 9 1725 2 10 1826 3 11 1927 4 12 2028 5 13 2129 6 14 2230 7 15 2331 8 16 2432	LED No	Status and Meaning	LED No	Status and Meaning
	PWR	Green: The system power supply is normal	RUN	Green: The module is running normally
		Green extinguishing: The system power supply is abnormal		Green extinguishing: The system power supply is abnormal
				Green flashing: Configuration failure/failsafe mode
	LED1-32	Green Light: Channels 1-32 input signal is valid		
		Green extinguishing: The input signal for channels 1-32 is invalid		

Terminal block

Serial number	Signal	illustrate	Serial number	Signal	illustrate
A1	DI 1	Digital input channel1	B1	DI 9	Digital input channel9
A2	DI 2	Digital input channel2	B2	DI 10	Digital input channel10
A3	DI 3	Digital input channel3	B3	DI 11	Digital input channel11
A4	DI 4	Digital input channel4	B4	DI 12	Digital input channel12
A5	DI 5	Digital input channel5	B5	DI 13	Digital input channel13
A6	DI 6	Digital input channel6	B6	DI 14	Digital input channel14
A7	DI 7	Digital input channel7	B7	DI 15	Digital input channel15
A8	DI 8	Digital input channel8	B8	DI 16	Digital input channel16
A9	COM1	Public end pin1	B9	COM2	Public end pin2
C1	DI 17	Digital input channel17	D1	DI 25	Digital input channel25
C2	DI 18	Digital input channel18	D2	DI 26	Digital input channel26
C3	DI 19	Digital input channel19	D3	DI 27	Digital input channel27
C4	DI 20	Digital input channel20	D4	DI 28	Digital input channel28

C5	DI 21	Digital input channel21	D5	DI 29	Digital input channel29
C6	DI 22	Digital input channel22	D6	DI 30	Digital input channel30
C7	DI 23	Digital input channel23	D7	DI 31	Digital input channel31
C8	DI 24	Digital input channel24	D8	DI 32	Digital input channel32
C9	COM3	Public end pin3	D9	COM4	Public end pin4


4.2.2 Specifications

Structural parameters		
Dimensions (WxHxD)		12mm x 100mm x 80mm
Weight		113.6g
Power Parameters		
The rated voltage of the USYS bus input power supply		5V DC +20%/−15% (4.25V DC~ 6V DC)
The USYS bus input power supply is rated current		<50mA (typical at 5V DC)
UOUT power supply input rated voltage		24 V DC +20%/−15% (20.4V DC~28.8V DC)
UOUT power supply input current rating		4A (typical at 24V DC)
UOUT power input anti-reverse plug protection		Yes
The module prevents the spread of power failures		Yes
Functional parameters		
Module type		Numeric input
Number of channels		32
Signal type		PNP&NPN
Connection type		1- Wire system
Signal type	“ON”	Differential pressure > 11VDC (differential pressure from

	Signal voltage	common input)
	“OFF” Signal voltage	Differential pressure < 5VDC (differential pressure from common input)
Input impedance		>7.5kΩ
Hardware response time		100us/100us
Whether to quarantine		是
Light status		When the input is valid, the input Light is on (software control)
Software parameters		
Data size		4 Byte
Error diagnosis		Communication diagnostics
Filter time configuration		Supports single-channel independent configuration
Sync mode		Synchronization within the same coupler group is supported
IO MAPPING		Support bit-by-bit, byte-by-byte, and word-by-word mapping
Wiring parameters		
Connectivity technology: 通信/现场总线		PROFINET IO: 2 x RJ-45
Connectivity technology		PUSH-IN type terminal blocks
Connection type		System/field power/input
Crimping area of the wire		0.34~1.5mm
Stripping length		10mm
Installation method:		DIN-35 TYPE RAIL
Material parameters		
Color		gy7042
Shell material		PC PLASTIC
Environmental requirements		
Allowable ambient		-20~55℃

temperature (during operation)	
Allowable ambient temperature (storage)	-40~85°C
Types of protection	IP20
Contamination level	2. Comply with IEC 61131-2 standard
Working altitude	0~2000m
Relative humidity (non-condensing)	5~95%RH
Anti-vibration	1g, in accordance with IEC 60068-2-6 standard
Impact resistance	15g, in accordance with IEC 60068-2-27
EMC ANTI-INTERFERENCE RATING	Zone B, IEC61131-2
Corrosion resistance	Compliant with IEC 60068-2-42 and IEC 60068-2-43 standards

4.2.3 Wiring diagram



4.3 DF30-M-16DO-N

4.3.1 Part description

16DO-N

P

☐

☐

R

1

☐

☐

9

2

☐

☐

10

3

☐

☐

11

4

☐

☐

12

5

☐

☐

13

6

☐

☐

14

7

☐

☐

15

8

☐

☐

16

Light						
	LED No	Status and Meaning	LED No	Status and Meaning		
	PWR	Green: The system power supply is normal	RUN	Green: The module is running normally		
		Green extinguishing: The system power supply is abnormal		Green extinguishing: The system power supply is abnormal		
				Green flashing: Configuration failure/failsafe mode		
	LED1-1	Green: Channels 1-16 output signal is valid				
	6	Green extinguishing: The output signal of channels 1-16 is invalid				
Terminal block						
Serial number	Signal	illustrate	Serial number	Signal	illustrate	
A1	D0 1	Digital output channel1	B1	D0 9	Digital output channel9	
A2	D0 2	Digital output channel2	B2	D0 10	Digital output channel10	
A3	D0 3	Digital output channel3	B3	D0 11	Digital output channel11	
A4	D0 4	Digital output channel4	B4	D0 12	Digital output channel12	
A5	D0 5	Digital output channel5	B5	D0 13	Digital output channel13	
A6	D0 6	Digital output channel6	B6	D0 14	Digital output channel14	
A7	D0 7	Digital output channel7	B7	D0 15	Digital output channel15	
A8	D0 8	Digital output channel8	B8	D0 16	Digital output channel16	
A9	24V	24V power input	B9	0V	0V input	


4.3.2 Specifications

Structural parameters		
Dimensions (WxHxD)		12mm x 100mm x 80mm
Weight		71.5g
Power Parameters		
The rated voltage of the USYS bus input power supply		5V DC +20%/-15% (4.25V DC~ 6V DC)
The USYS bus input power supply is rated current		<60mA (typical at 5V DC)
UOUT power supply input rated voltage		24 V DC +20%/-15% (20.4V DC~28.8V DC)
UOUT power supply input current rating		4A (typical at 24V DC)
UOUT power input anti-reverse plug protection		Yes
The module prevents the spread of power failures		Yes
Functional parameters		
Module type		Digital output
Number of channels		16
Signal type		NPN
Connection type		1- Wire system
Power supply input	24V	24V power input
Rated voltage	0V	0V input
NPN Signal type	“ON” Signal voltage	0V DC
	“OFF” Signal	High impedance state, leakage current < 0.1mA

	voltage	
Output Load (Resistive Load)	0.5A/point, 4A/module	
Output Load (Inductive Load)	7.2W/dot, 24W/module	
Output load (light load)	5W/point, 18W/module	
Switching frequency	Resistive load 100Hz, inductive load 0.5Hz, lamp load 10Hz	
Hardware response time	100us/100us	
Output decreasing	Derated by 50% when operating at 55° C (the output current does not exceed 2A when ON) at the same time, or derated by 10° C when the output point is fully ON	
Whether to quarantine	Yes	
Protection function	Over-temperature shutdown: minimum value 150° C. Typical value 175° C Overcurrent protection: 3A Support short-circuit protection	
Light status	When the output is active, the output Light is on (software control)	
Software parameters		
Data size	2 Byte	
Error diagnosis	Communication diagnostics, power supply diagnostics, channel overcurrent diagnostics	
Communication fault output state mode	Maintains current value, outputs to replacement value (configurable)	
Overcurrent fault output state mode	Auto Retry, Stop Output (Configurable)	
Sync mode	Synchronization within the same coupler group is supported	
IO MAPPING	Support bit-by-bit, byte-by-byte, and word-by-word mapping	
Wiring parameters		
Connectivity technology	PUSH-IN type terminal blocks	
Connection type	System/field power/input	

Crimping area of the wire	0.34~1.5mm
Stripping length	10mm
Installation method:	DIN-35 TYPE RAIL
Material parameters	
Color	Pantone 419C
Shell material	PC PLASTIC
Environmental requirements	
Allowable ambient temperature (during operation)	-20~55°C
Allowable ambient temperature (storage)	-40~85°C
Types of protection	IP20
Contamination level	2. Comply with IEC 61131-2 standard
Working altitude	0~2000m
Relative humidity (non-condensing)	5~95%RH
Anti-vibration	1g, in accordance with IEC 60068-2-6 standard
Impact resistance	15g, in accordance with IEC 60068-2-27
EMC ANTI-INTERFERENCE RATING	Zone B, IEC61131-2
Corrosion resistance	Compliant with IEC 60068-2-42 and IEC 60068-2-43 standards

4.3.3 Wiring diagram



4.4 DF30-M-16DO-P

4.4.1 Part description

16DO-P P R 1 9 2 10 3 11 4 12 5 13 6 14 7 15 8 16	LED No	Status and Meaning		LED No	Status and Meaning	
	PWR	Green: The system power supply is normal		RUN	Green: The module is running normally	
		Green extinguishing: The system power supply is abnormal			Green extinguishing: The system power supply is abnormal	
					Green flashing: Configuration failure/failsafe mode	
	LED1-1	Green: Channels 1-16 output signal is valid				
	6	Green extinguishing: The output signal of channels 1-16 is invalid				
Terminal block						
Serial number	Signal	illustrate		Serial number	Signal	illustrate
A1	DO 1	Digital output channel1		B1	DO 9	Digital output channel9

A2	D0 2	Digital output channel2	B2	D0 10	Digital output channel10
A3	D0 3	Digital output channel3	B3	D0 11	Digital output channel11
A4	D0 4	Digital output channel4	B4	D0 12	Digital output channel12
A5	D0 5	Digital output channel5	B5	D0 13	Digital output channel13
A6	D0 6	Digital output channel6	B6	D0 14	Digital output channel14
A7	D0 7	Digital output channel7	B7	D0 15	Digital output channel15
A8	D0 8	Digital output channel8	B8	D0 16	Digital output channel16
A9	24V	24V power input	B9	0V	0V input

4.4.2 Specifications


Structural parameters	
Dimensions (WxHxD)	12mm x 100mm x 80mm
Weight	71.5g
Power Parameters	
The rated voltage of the USYS bus input power supply	5V DC +20%/-15% (4.25V DC~ 6V DC)
The USYS bus input power supply is rated current	<60mA (typical at 5V DC)
UOUT power supply input rated voltage	24 V DC +20%/-15% (20.4V DC~28.8V DC)
UOUT power supply input current rating	4A (typical at 24V DC)
UOUT power input anti-reverse plug protection	Yes
The module prevents the spread of power failures	Yes
Functional parameters	
Module type	Digital output
Number of channels	16
Signal type	PNP

Connection type		1- Wire system
Power supply input	24V	24V power input
Rated voltage	0V	0V input
PNP Signal type	“ON” Signal voltage	24V DC
	“OFF” Signal voltage	High impedance state, leakage current < 0.1mA
Output Load (Resistive Load)		0.5A/point, 4A/module
Output Load (Inductive Load)		7.2W/dot, 24W/module
Output load (light load)		5W/point, 18W/module
Switching frequency		Resistive load 100Hz, inductive load 0.5Hz, lamp load 10Hz
Hardware response time		100us/100us
Output decreasing		Derated by 50% when operating at 55° C (the output current does not exceed 2A when ON) at the same time, or derated by 10° C when the output point is fully ON
Whether to quarantine		Yes
Protection function		Thermal shutdown: 175° C typical Overcurrent protection: 1A Support short-circuit protection
Light status		When the output is active, the output Light is on (software control)
Software parameters		
Data size		2 Byte
Error diagnosis		Communication diagnostics, power supply diagnostics, channel overcurrent diagnostics
Communication fault output		Maintains current value, outputs to replacement value

state mode	(configurable)
Overcurrent fault output state mode	Auto Retry, Stop Output (Configurable)
Sync mode	Synchronization within the same coupler group is supported
IO MAPPING	Support bit-by-bit, byte-by-byte, and word-by-word mapping
Wiring parameters	
Connectivity technology	PUSH-IN type terminal blocks
Connection type	System/field power/input
Crimping area of the wire	0.34~1.5mm
Stripping length	10mm
Installation method:	DIN-35 TYPE RAIL
Material parameters	
Color	Pantone 419C
Shell material	PC PLASTIC
Environmental requirements	
Allowable ambient temperature (during operation)	-20~55°C
Allowable ambient temperature (storage)	-40~85°C
Types of protection	IP20
Contamination level	2. Comply with IEC 61131-2 standard
Working altitude	0~2000m
Relative humidity (non-condensing)	5~95%RH
Anti-vibration	1g, in accordance with IEC 60068-2-6 standard
Impact resistance	15g, in accordance with IEC 60068-2-27
EMC ANTI-INTERFERENCE RATING	Zone B, IEC61131-2

Corrosion resistance	Compliant with IEC 60068-2-42 and IEC 60068-2-43 standards
----------------------	--

4.4.3 Wiring diagram



4.5 DF30-M-32DO-P

4.5.1 Part description

Light				
32DO-P ☐ P ☐ R 1 ☐ 9 ☐ 17 ☐ 25 2 ☐ 10 ☐ 18 ☐ 26 3 ☐ 11 ☐ 19 ☐ 27 4 ☐ 12 ☐ 20 ☐ 28 5 ☐ 13 ☐ 21 ☐ 29 6 ☐ 14 ☐ 22 ☐ 30 7 ☐ 15 ☐ 23 ☐ 31 8 ☐ 16 ☐ 24 ☐ 32	LED No	Status and Meaning	LED No	Status and Meaning
	PWR	Green: The system power supply is normal	RUN	Green: The module is running normally
		Green extinguishing: The system power supply is abnormal		Green extinguishing: The system power supply is abnormal
				Green flashing: Configuration failure/failsafe mode

		LED1-32	Green: Channels 1-32 output signal is valid		
			Green extinguishing: The output signal of channels 1-32 is invalid		
Terminal block					
Serial number	Signal	illustrate	Serial number	Signal	illustrate
A1	D0 1	Digital output channel1	B1	D0 9	Digital output channel9
A2	D0 2	Digital output channel2	B2	D0 10	Digital output channel10
A3	D0 3	Digital output channel3	B3	D0 11	Digital output channel11
A4	D0 4	Digital output channel4	B4	D0 12	Digital output channel12
A5	D0 5	Digital output channel5	B5	D0 13	Digital output channel13
A6	D0 6	Digital output channel6	B6	D0 14	Digital output channel14
A7	D0 7	Digital output channel7	B7	D0 15	Digital output channel15
A8	D0 8	Digital output channel8	B8	D0 16	Digital output channel16
A9	24V	24V power input	B9	0V	0V input
C1	D0 17	Digital output channel17	D1	D0 25	Digital output channel25
C2	D0 18	Digital output channel18	D2	D0 26	Digital output channel26
C3	D0 19	Digital output channel19	D3	D0 27	Digital output channel27
C4	D0 20	Digital output channel20	D4	D0 28	Digital output channel28
C5	D0 21	Digital output channel21	D5	D0 29	Digital output channel29
C6	D0 22	Digital output channel22	D6	D0 30	Digital output channel30
C7	D0 23	Digital output channel23	D7	D0 31	Digital output channel31
C8	D0 24	Digital output channel24	D8	D0 32	Digital output channel32
C9	24V	24V power input	D9	0V	0V input

4.5.2 Specifications


Structural parameters	
Dimensions (WxHxD)	12mm x 100mm x 80mm
Weight	113.6g
Power Parameters	

The rated voltage of the USYS bus input power supply		5V DC +20%/-15% (4.25V DC~ 6V DC)
The USYS bus input power supply is rated current		<60mA (typical at 5V DC)
UOUT power supply input rated voltage		24 V DC +20%/-15% (20.4V DC~28.8V DC)
UOUT power supply input current rating		4A (typical at 24V DC)
UOUT power input anti-reverse plug protection		Yes
The module prevents the spread of power failures		Yes
Functional parameters		
Module type		Digital output
Number of channels		32
Signal type		PNP
Connection type		1- Wire system
Power supply input	24V	24V power input
Rated voltage	0V	0V input
PNPSignal type	“ON” Signal voltage	24V DC
	“OFF” Signal voltage	High configuration, leakage current < 0.1mA
Output Load (Resistive Load)		0.5A/point, 8A/module
Output Load (Inductive Load)		7.2W/dot, 48W/module
Output load (light load)		5W/dot, 36W/module

Switching frequency	Resistive load 100Hz, inductive load 0.5Hz, lamp load 10Hz
Hardware response time	100us/100us
Output decreasing	Derating by 50% when operating at 55° C (the output current does not exceed 4A when turned on at the same time), or derating by 10° C when the output point is fully ON
Whether to quarantine	是
Protection function	Thermal shutdown: 175° C typical Overcurrent protection: 1A Support short-circuit protection
Light status	When the output is active, the output Light is on (software control)
Software parameters	
Data size	4 Byte
Error diagnosis	Communication diagnostics, power supply diagnostics, channel overcurrent diagnostics
Communication fault output state mode	Keep the current value and output as the replacement value
Overcurrent fault output state mode	Auto Retry, Stop Output (Configurable)
Sync mode	Synchronization within the same coupler group is supported
IO MAPPING	Support bit-by-bit, byte-by-byte, and word-by-word mapping
Wiring parameters	
Connectivity technology: Communications/fieldbuses	PROFINET IO: 2 x RJ-45
Connectivity technology	PUSH-IN type terminal blocks
Connection type	System/field power/input
Crimping area of the wire	0.34~1.5mm
Stripping length	10mm
Installation method:	DIN-35 TYPE RAIL

Material parameters	
Color	gy7042
Shell material	PC PLASTIC
Environmental requirements	
Allowable ambient temperature (during operation)	-20~55℃
Allowable ambient temperature (storage)	-40~85℃
Types of protection	IP20
Contamination level	2. Comply with IEC 61131-2 standard
Working altitude	0~2000m
Relative humidity (non-condensing)	5~95%RH
Anti-vibration	1g, in accordance with IEC 60068-2-6 standard
Impact resistance	15g, in accordance with IEC 60068-2-27
EMC ANTI-INTERFERENCE RATING	Zone B, IEC61131-2
Corrosion resistance	Compliant with IEC 60068-2-42 and IEC 60068-2-43 standards

4.5.3 Wiring diagram



4.6 DF30-M-32DO-N
4.6.1 Part description

Light						
32DO-N P R 1 9 17 25 2 10 18 26 3 11 19 27 4 12 20 28 5 13 21 29 6 14 22 30 7 15 23 31 8 16 24 32	LED No	Status and Meaning	LED No	Status and Meaning		
	PWR	Green: The system power supply is normal	RUN	Green: The module is running normally		
		Green extinguishing: The system power supply is abnormal		Green extinguishing: The system power supply is abnormal		
				Green flashing: Configuration failure/failsafe mode		
		LED1	Green: Channels 1–32 output signal is valid			
		–32	Green extinguishing: The output signal of channels 1–32 is invalid			
Terminal block						
Serial number	Signal	illustrate	Serial number	Signal	illustrate	
A1	D0 1	Digital output channel1	B1	D0 9	Digital output channel9	
A2	D0 2	Digital output channel2	B2	D0 10	Digital output channel10	
A3	D0 3	Digital output channel3	B3	D0 11	Digital output channel11	
A4	D0 4	Digital output channel4	B4	D0 12	Digital output channel12	
A5	D0 5	Digital output channel5	B5	D0 13	Digital output channel13	
A6	D0 6	Digital output channel6	B6	D0 14	Digital output channel14	
A7	D0 7	Digital output channel7	B7	D0 15	Digital output channel15	
A8	D0 8	Digital output channel8	B8	D0 16	Digital output channel16	
A9	24V	24V power input	B9	0V	0V input	
C1	D0 17	Digital output channel17	D1	D0 25	Digital output channel25	
C2	D0 18	Digital output channel18	D2	D0 26	Digital output channel26	
C3	D0 19	Digital output channel19	D3	D0 27	Digital output channel27	

C4	D0 20	Digital output channel20	D4	D0 28	Digital output channel28
C5	D0 21	Digital output channel21	D5	D0 29	Digital output channel29
C6	D0 22	Digital output channel22	D6	D0 30	Digital output channel30
C7	D0 23	Digital output channel23	D7	D0 31	Digital output channel31
C8	D0 24	Digital output channel24	D8	D0 32	Digital output channel32
C9	24V	24V power input	D9	0V	0V input

4.6.2 Specifications


Structural parameters		
Dimensions (WxHxD)		12mm x 100mm x 80mm
Weight		113.6g
Power Parameters		
The rated voltage of the USYS bus input power supply		5V DC +20%/-15% (4.25V DC~ 6V DC)
The USYS bus input power supply is rated current		<60mA (typical at 5V DC)
UOUT power supply input rated voltage		24 V DC +20%/-15% (20.4V DC~28.8V DC)
UOUT power supply input current rating		(typical at 24V DC)
UOUT power input anti-reverse plug protection		Yes
The module prevents the spread of power failures		Yes
Functional parameters		
Module type		Digital output
Number of channels		32
Signal type		NPN
Connection type		1- Wire system
Power supply	24V	24V power input

input Rated voltage	0V	0V input
NPNSignal type	“ON” Signal voltage	24V DC
	“OFF” Signal voltage	High configuration, leakage current < 0.1mA
Output Load (Resistive Load)		0.5A/point, 8A/module
Output Load (Inductive Load)		7.2A/point, 48W/module
Output load (light load)		5W/dot, 36W/module
Switching frequency		Resistive load 100Hz, inductive load 0.5Hz, lamp load 10Hz
Hardware response time		100us/100us
Output decreasing		Derating by 50% when operating at 55° C (the output current does not exceed 4A when turned on at the same time), or derating by 10° C when the output point is fully ON
Whether to quarantine		Yes
Protection function		Over-temperature shutdown: minimum value 150° C. Typical value 175° C Overcurrent protection: 3A Support short-circuit protection
Light status		When the output is active, the output Light is on (software control)
Software parameters		
Data size		4 Byte
Error diagnosis		Communication diagnostics, power supply diagnostics, channel overcurrent diagnostics
Communication fault output state mode		Keep the current value and output as the replacement value

Overcurrent fault output state mode	Automatic retries
Sync mode	Synchronization within the same coupler group is supported
IO MAPPING	Support bit-by-bit, byte-by-byte, and word-by-word mapping
Wiring parameters	
Connectivity technology: Communications/fieldbuses	PROFINET IO: 2 x RJ-45
Connectivity technology	PUSH-IN type terminal blocks
Connection type	System/field power/input
Crimping area of the wire	0.34~1.5mm
Stripping length	10mm
Installation method:	DIN-35 TYPE RAIL
Material parameters	
Color	gy7042
Shell material	PC PLASTIC
Environmental requirements	
Allowable ambient temperature (during operation)	-20~55°C
Allowable ambient temperature (storage)	-40~85°C
Types of protection	IP20
Contamination level	2. Comply with IEC 61131-2 standard
Working altitude	0~2000m
Relative humidity (non-condensing)	5~95%RH
Anti-vibration	1g, in accordance with IEC 60068-2-6 standard
Impact resistance	15g, in accordance with IEC 60068-2-27


EMC ANTI-INTERFERENCE RATING	Zone B, IEC61131-2
Corrosion resistance	Compliant with IEC 60068-2-42 and IEC 60068-2-43 standards

4.6.3 Wiring diagram



4.7 DF30-M-4AI-UI

4.7.1 Part description

Light				
	LED No	Status and Meaning	LED No	Status and Meaning
	PWR	Green: The system power supply is normal	RUN	Green: The module is running normally
		Green extinguishing: The system power supply is abnormal		Green extinguishing: The system power supply is abnormal
				Green flashing: Configuration failure/failsafe mode
	LED1-4	Green: Channels 1-4 input Signal is valid		
		Green extinguished: Channels 1-4 input signal is invalid		

		Green flashing: When the diagnostic switch for channels 1-4 is turned on, the corresponding input channel fault is affected			
Terminal block					
Serial number	Signal	illustrate	Serial number	Signal	illustrate
A1	U1+	Analog voltage input channel1	B1	U1-	Analog voltage input channel1
A2	U2+	Analog voltage input channel2	B2	U2-	Analog voltage input channel2
A3	U3+	Analog voltage input channel3	B3	U3-	Analog voltage input channel3
A4	U4+	Analog voltage input channel4	B4	U4-	Analog voltage input channel4
A5	I1+	Analog current input channel1	B5	I1-	Analog current input channel1
A6	I2+	Analog current input channel2	B6	I2-	Analog current input channel2
A7	I3+	Analog current input channel3	B7	I3-	Analog current input channel3
A8	I4+	Analog current input channel4	B8	I4-	Analog current input channel4
A9	24V	24V power output	B9	0V	0V output

4.7.2 Specifications


Structural parameters	
Dimensions (WxHxD)	12mm x 100mm x 80mm
Weight	71.5g
Power Parameters	
The rated voltage of the USYS bus input power supply	5V DC +20%/-15% (4.25V DC~ 6V DC)

The USYS bus input power supply is rated current	<50mA
UIN power supply input rated voltage	24 V DC (20.4V DC~28.8V DC)
UIN power supply input current rating	<50mA non-distribution
	< 250mA power distribution
UIN power input anti-reverse plug protection	Yes
Functional parameters	
Module type	Analog voltage and current input module
Number of channels	4
Signal type	Voltage/current
Connection type	2-wire power distribution, 4-wire non-power distribution
Channel mode configuration	Disable, 0~10mA、0~20mA、4~20mA、 $\pm 10V$ 、0~10V、2~10V、 $\pm 5V$ 、0~5V、1~5V
Voltage input accuracy	$\pm 0.1\%$ ($\pm 10V$ full scale).
voltageInput impedance	>400K Ω
Voltage input limit	$\pm 15V$
Voltage input diagnostics	Over-limit detection, 2~10V, 1~5V support disconnection detection
Current sampling impedance	$\leq 250\Omega$
Current input accuracy	$\pm 0.1\%$ (20mA full scale).
Current input limit	30mA
Current input diagnostics	Over-limit detection, 4~20mA supports disconnection detection
Whether to quarantine	The interface channels are not isolated, and the interface is isolated from the bus
Input action display	When the input signal is active, the input channel light is solid (software control)

Software parameters	
Sampling period	1ms (4 channels)
Filtering method	Sliding window filtering, debounce filtering, 50HZ/60HZ anti-power frequency
Data size	8 Byte
Error diagnosis	Communication diagnosis, power supply diagnosis, channel overrun diagnosis, channel disconnection diagnosis
IO MAPPING	Word-by-word mapping is supported
Wiring parameters	
Connectivity technology	PUSH-IN type terminal blocks
Connection type	System/field power/input
Crimping area of the wire	0.34~1.5mm
Stripping length	10mm
Installation method:	DIN-35 TYPE RAIL
Material parameters	
Color	Pantone 419C
Shell material	PC PLASTIC
Environmental requirements	
Allowable ambient temperature (during operation)	-20~55°C
Allowable ambient temperature (storage)	-40~85°C
Types of protection	IP20
Contamination level	2. Comply with IEC 61131-2 standard
Working altitude	0~2000m
Relative humidity (non-condensing)	5~95%RH
Anti-vibration	1g, in accordance with IEC 60068-2-6 standard

Impact resistance	15g, in accordance with IEC 60068-2-27
EMC ANTI-INTERFERENCE RATING	Zone B, IEC61131-2
Corrosion resistance	Compliant with IEC 60068-2-42 and IEC 60068-2-43 standards

4.7.3 Wiring diagram



Concentrate:

- If the sensor enumeration item in channel 1 is configured as $0 \sim 10\text{mA} \sim 4 \sim 20\text{mA}$, then channel 1 is the current detection mode, and the sensor is connected to the A5 ~ B5 channel; If the sensor enumeration item in channel 1 is configured as $-10\text{V} \sim +10\text{V} \sim 1\text{V} \sim 5\text{V}$, then channel 1 is in voltage detection mode, and the sensor is connected to channel A1 ~ B1;
- If the sensor enumeration in channel 2 is configured as $0 \sim 10\text{mA} \sim 4 \sim 20\text{mA}$, channel 2 is the current detection mode, and the sensor is connected to the A6 ~ B6 channel; If the sensor enumeration on channel 2 is configured as $-10\text{V} \sim +10\text{V} \sim 1\text{V} \sim 5\text{V}$, then channel 2 is in voltage detection mode, the sensor is connected to channel A2 ~ B2, and so on for other channels.

4.8 DF30-M-4AO-UI

4.8.1 Part description

Light						
4AO-UI P☐ ☐ R 1☐ 2☐ 3☐ 4☐	LED No	Status and Meaning	LED No	Status and Meaning		
	PWR	Green: The system power supply is normal	RUN	Green: The module is running normally		
		Green extinguishing: The system power supply is abnormal		Green extinguishing: The system power supply is abnormal		
				Green flashing: Configuration failure/failsafe mode		
	LED1-4	Green: Channel 1-4 output signal is valid				
		Green extinguishing: The output signal of channels 1-4 is invalid				
Terminal block						
Serial number	Signal	illustrate	Serial number	Signal	illustrate	
A1	U1+	Analog voltage output channel1	B1	U1-	Analog voltage output channel1	
A2	U2+	Analog voltage output channel2	B2	U2-	Analog voltage output channel2	
A3	U3+	Analog voltage output channel3	B3	U3-	Analog voltage output channel3	
A4	U4+	Analog voltage output channel4	B4	U4-	Analog voltage output channel4	
A5	I1+	Analog current output channel1	B5	I1-	Analog current output channel1	
A6	I2+	Analog current output channel2	B6	I2-	Analog current output channel2	
A7	I3+	Analog current output channel3	B7	I3-	Analog current output channel3	

A8	I4+	Analog current output channel4	B8	I4-	Analog current output channel4
A9	24V	24V power input	B9	0V	0V input


4.8.2 Specifications

Structural parameters	
Dimensions (WxHxD)	12mm x 100mm x 80mm
Weight	71.5g
Power Parameters	
The rated voltage of the USYS bus input power supply	5V DC +20%/-15% (4.25V DC~ 6V DC)
The USYS bus input power supply is rated current	<50mA (typical at 5V DC)
UOUT power supply input rated voltage	24 V DC +20%/-15% (20.4V DC~28.8V DC)
UOUT power supply input current rating	<200mA
UOUT power input anti-reverse plug protection	Yes
Functional parameters	
Module type	Analog voltage current output
Number of channels	4
Signal type	Voltage/current
Connection type	2-wire power distribution, 4-wire non-power distribution
Voltage output range	$\pm 10V$ 、0~10V、2~10V、 $\pm 5V$ 、0~5V、1~5V
Voltage output load	>1k Ω
Voltage output accuracy	$\pm 0.1\%$
Current output range	0~10mA、0~20mA、4~20mA
current output load	0~10mA: <1.5k Ω

	other: <600Ω
Current output accuracy	±0.1%
Whether to quarantine	The interface channels are not isolated, the power supply is isolated from the interface, and the interface is isolated from the bus
Output action display	When the output is active, the output Light is on (software control)
Software parameters	
Convert the range of digital quantities	-20000~20000, -32000~32000, -27648~27648
IO process data size	16byte
Error diagnosis	Communication diagnostics, power supply diagnostics, output open circuits (effective when current is output)
Sync mode	Synchronization within the same coupler group is supported
IO MAPPING	Word-by-word mapping is supported
Wiring parameters	
Connectivity technology	PUSH-IN type terminal blocks
Connection type	System/field power/input
Crimping area of the wire	0.34~1.5mm
Stripping length	10mm
Installation method:	DIN-35 TYPE RAIL
Material parameters	
Color	Pantone 419C
Shell material	PC PLASTIC
Environmental requirements	
Allowable ambient temperature (during operation)	-20~55°C
Allowable ambient	-40~85°C

temperature (storage)	
Types of protection	IP20
Contamination level	2. Comply with IEC 61131-2 standard
Working altitude	0~2000m
Relative humidity (non-condensing)	5~95%RH
Anti-vibration	1g, in accordance with IEC 60068-2-6 standard
Impact resistance	15g, in accordance with IEC 60068-2-27
EMC ANTI-INTERFERENCE RATING	Zone B, IEC61131-2
Corrosion resistance	Compliant with IEC 60068-2-42 and IEC 60068-2-43 standards

4.8.3 Wiring diagram




4.9.2 Specifications

Structural parameters	
Dimensions (WxHxD)	12mm x 100mm x 80mm
Weight	71.5g
Power Parameters	
The rated voltage of the USYS bus input power supply	5V DC +20%/-15% (4.25V DC~ 6V DC)
The USYS bus input power supply is rated current	<50mA
UIN power supply input rated voltage	24 V DC (20.4V DC~28.8V DC)
UIN power supply input current rating	<50mA non-distribution
	< 250mA power distribution
UIN power input anti-reverse plug protection	Yes
The module prevents the spread of power failures	Yes
Functional parameters	
Module type	Analog input module
Number of channels	8
Signal type	current
Connection type	2-wire power distribution, 4-wire non-power distribution
Maximum input range of current	0~10mA: 0~12.5mA 0~20mA: 0~24mA 4~20mA: 1.19~24mA
Current harvesting impedance	≤250Ω
Current input accuracy	±0.1% (full scale)
Drift	±50ppm/K
Current protection	30mA

Current input diagnostics	Over-limit detection, 4~20mA supports disconnection detection
Whether to quarantine	The interface channels are not isolated, the power supply is isolated from the interface, and the interface is isolated from the bus
Independent channel enable configuration	Yes
Diagnose and report feature configurations	Yes
Channel mode configuration	Disable, 0~10mA, 0~20mA, 4~20mA
Input action display	When the input Signal is valid, the input Light is solid
Channel reverse polarity protection	Yes
The channel is anti-24V misconnected	Yes
Software parameters	
Sampling period	1.6ms (8 channels)
Filtering method	Sliding window filtering, debounce filtering, 50HZ/60HZ anti-power frequency
Data size	16 Byte
Error diagnosis	Communication diagnosis, power supply diagnosis, channel overrun diagnosis, channel disconnection diagnosis
IO MAPPING	Word-by-word mapping is supported
Wiring parameters	
Connectivity technology	PUSH-IN type terminal blocks
Connection type	System/field power/input
Crimping area of the wire	0.34~1.5mm
Stripping length	10mm
Installation method:	DIN-35 TYPE RAIL

Material parameters	
Color	Pantone 419C
Shell material	PC PLASTIC
Environmental requirements	
Allowable ambient temperature (during operation)	-20~55°C
Allowable ambient temperature (storage)	-40~85°C
Types of protection	IP20
Contamination level	2. Comply with IEC 61131-2 standard
Working altitude	0~2000m
Relative humidity (non-condensing)	5~95%RH
Anti-vibration	1g, in accordance with IEC 60068-2-6 standard
Impact resistance	15g, in accordance with IEC 60068-2-27
EMC ANTI-INTERFERENCE RATING	Zone B, IEC61131-2
Corrosion resistance	Compliant with IEC 60068-2-42 and IEC 60068-2-43 standards

4.9.3 Wiring diagram



4.10 DF30-M-8AO-I

4.10.1 Part description

Light						
8AI-U P☐ ☐R 1☐ 2☐ 3☐ 4☐ 5☐ 6☐ 7☐ 8☐	LED No	Status and Meaning	LED No	Status and Meaning		
	PWR	Green: The system power supply is normal	RUN	Green: The module is running normally		
		Green extinguishing: The system power supply is abnormal		Green extinguishing: The system power supply is abnormal		
				Green flashing: Configuration failure/failsafe mode		
	LED1-8	Green: Channels 1-8 output signal is valid				
		Green extinguishing: Channels 1-8 output signal abnormal				
	Terminal block					
Serial number	Signal	illustrate	Serial number	Signal	illustrate	

A1	I1+	Current output channel1	B1	I1-	Current output channel1
A2	I2+	Current output channel2	B2	I2-	Current output channel2
A3	I3+	Current output channel3	B3	I3-	Current output channel3
A4	I4+	Current output channel4	B4	I4-	Current output channel4
A5	I5+	Current output channel5	B5	I5-	Current output channel5
A6	I6+	Current output channel6	B6	I6-	Current output channel6
A7	I7+	Current output channel7	B7	I7-	Current output channel7
A8	I8+	Current output channel8	B8	I8-	Current output channel8
A9	24V	24V power input	B9	0V	0V input


4.10.2 Specifications

Structural parameters	
Dimensions (WxHxD)	12mm x 100mm x 80mm
Weight	71.5g
Power Parameters	
The rated voltage of the USYS bus input power supply	5V DC +20%/-15% (4.25V DC~ 6V DC)
The USYS bus input power supply is rated current	<50mA (typical at 5V DC)
UOUT power supply input rated voltage	24 V DC +20%/-15% (20.4V DC~28.8V DC)
UOUT power supply input current rating	<200mA
UOUT power input anti-reverse plug protection	Yes
Functional parameters	
Module type	Analog output
Number of channels	8
Signal type	current

Current output range	0~10ma: 0~12.5ma 0~20ma: 0~24ma 4~20ma: 1.19~24ma
Current output load	0~10ma: <1.5k Ω other: <600 Ω
Current output accuracy	$\pm 0.1\%$ (Full scale)
Channel mode configuration	Disable, 0~10ma, 0~20ma, 4~20ma
Whether to quarantine	The interface channel is not isolated, the interface is isolated from the bus, 500VAC
Drift	$\pm 50\text{ppm/k}$
Output response time	10%~90% Step jump: <100ms
Diagnostic tests	Communication diagnosis, power supply diagnosis, output open circuit
Output status configuration after shutdown	Keep the current output or output preset
Stop mode	Press the faildown state mode and no longer refresh
Output action display	When the output signal is active, the Light is solid
Software parameters	
Convert the range of digital quantities	0~20000, 0~32000, 0~27648
IO 过程 Data size	16byte
Error diagnosis	Communication diagnosis, power supply diagnosis, output open circuit
Sync mode	Synchronization within the same coupler group is supported
IO MAPPING	Word-by-word mapping is supported
Wiring parameters	
Connectivity technology	PUSH-IN type terminal blocks
Connection type	System/field power/input
Crimping area of the wire	0.34~1.5mm


Stripping length	10mm
Installation method:	DIN-35 TYPE RAIL
Material parameters	
Color	Pantone 419C
Shell material	PC PLASTIC
Environmental requirements	
Allowable ambient temperature (during operation)	-20~55°C
Allowable ambient temperature (storage)	-40~85°C
Types of protection	IP20
Contamination level	2. Comply with IEC 61131-2 standard
Working altitude	0~2000m
Relative humidity (non-condensing)	5~95%RH
Anti-vibration	1g, in accordance with IEC 60068-2-6 standard
Impact resistance	15g, in accordance with IEC 60068-2-27
EMC ANTI-INTERFERENCE RATING	Zone B, IEC61131-2
Corrosion resistance	Compliant with IEC 60068-2-42 and IEC 60068-2-43 standards

4.10.3 Wiring diagram



4.11 DF30-M-8AI-U

4.11.1 Part description

Light				
	LED No	Status and Meaning	LED No	Status and Meaning
	PWR	Green: The system power supply is normal	RUN	Green: The module is running normally
		Green extinguishing: The system power supply is abnormal		Green extinguishing: The system power supply is abnormal
				Green flashing: Configuration failure/failsafe mode
	LED1-8	Green light: Channels 1-8 input Signal is valid		
		Green extinguishing: Channels 1-8 input signal is invalid		
		Green flashing: When the input diagnostic switch on channels 1-8 is turned on, the corresponding channel input fault		
Terminal block				

Serial number	Signal	illustrate	Serial number	Signal	illustrate
A1	U1+	Voltage input channel1	B1	U1-	Voltage input channel1
A2	U2+	Voltage input channel2	B2	U2-	Voltage input channel2
A3	U3+	Voltage input channel3	B3	U3-	Voltage input channel3
A4	U4+	Voltage input channel4	B4	U4-	Voltage input channel4
A5	U5+	Voltage input channel5	B5	U5-	Voltage input channel5
A6	U6+	Voltage input channel6	B6	U6-	Voltage input channel6
A7	U7+	Voltage input channel7	B7	U7-	Voltage input channel7
A8	U8+	Voltage input channel8	B8	U8-	Voltage input channel8
A9	24V	24V power output	B9	0V	0V output


4. 11. 2 Specifications

Structural parameters	
Dimensions (WxHxD)	12mm x 100mm x 80mm
Weight	71.5g
Power Parameters	
The rated voltage of the USYS bus input power supply	5V DC +20%/-15% (4. 25V DC~ 6V DC)
The USYS bus input power supply is rated current	<50m
UIN power supply input rated voltage	24 V DC (20. 4V DC~28. 8V DC)
UIN power supply input current rating	<50mA non-distribution
	<250mA power distribution
UIN power input anti-reverse plug protection	Yes
The module prevents the spread of power failures	Yes
Functional parameters	

Module type	Analog input module
Number of channels	8
Signal type	voltage
Connection type	2-wire power distribution, 4-wire non-power distribution
Voltage input range	$\pm 10V$ 、 $0\sim 10V$ 、 $2\sim 10V$ 、 $\pm 5V$ 、 $0\sim 5V$ 、 $1\sim 5V$
Input impedance	$>400K\Omega$
Voltage input accuracy	$\pm 0.1\%$ (Full scale)
Drift	$\pm 50\text{ppm/K}$
Voltage protection	24V
Voltage input diagnostics	$2\sim 10V$ 、 $1\sim 5V$ support disconnection detection
Whether to quarantine	The interface channels are not isolated, and the interface is isolated from the bus
Independent channel enable configuration	Yes
Diagnose and report feature configurations	Yes
Channel mode configuration	Disable、 $\pm 10V$ 、 $0\sim 10V$ 、 $2\sim 10V$ 、 $\pm 5V$ 、 $0\sim 5V$ 、 $1\sim 5V$
Input action display	When the input Signal is valid, the input Light is solid
The channel is anti-24V misconnected	Yes
Software parameters	
Sampling period	1.6ms (8 channels)
Filtering method	Sliding window filtering, dejitter filtering, 50HZ\60HZ anti-power frequency
Data size	16 Byte
Error diagnosis	Communication diagnosis, power supply diagnosis, channel overrun diagnosis, channel disconnection diagnosis
IO MAPPING	Word-by-word mapping is supported
Wiring parameters	

Connectivity technology	PUSH-IN type terminal blocks
Connection type	System/field power/input
Crimping area of the wire	0.34~1.5mm
Stripping length	10mm
Installation method:	DIN-35 TYPE RAIL
Material parameters	
Color	Pantone 419C
Shell material	PC PLASTIC
Environmental requirements	
Allowable ambient temperature (during operation)	-20~55°C
Allowable ambient temperature (storage)	-40~85°C
Types of protection	IP20
Contamination level	2. Comply with IEC 61131-2 standard
Working altitude	0~2000m
Relative humidity (non-condensing)	5~95%RH
Anti-vibration	1g, in accordance with IEC 60068-2-6 standard
Impact resistance	15g, in accordance with IEC 60068-2-27
EMC ANTI-INTERFERENCE RATING	Zone B, IEC61131-2
Corrosion resistance	Compliant with IEC 60068-2-42 and IEC 60068-2-43 standards

4.11.3 Wiring diagram



4.12 DF30-M-8AO-U

4.12.1 Part description

Light						
8AO-U P☐ ☐ R 1☐ 2☐ 3☐ 4☐ 5☐ 6☐ 7☐ 8☐	LED No	Status and Meaning	LED No	Status and Meaning		
	PWR	Green: The system power supply is normal	RUN	Green: The module is running normally		
		Green extinguishing: The system power supply is abnormal		Green extinguishing: The system power supply is abnormal		
				Green flashing: Configuration failure/failsafe mode		
	LED1-8	Green: Channels 1-8 output signal is valid				
		Green extinguishing: The output signal of channels 1-8 is invalid				
Terminal block						
Serial number	Signal	illustrate	Serial number	Signal	illustrate	

A1	U1+	Voltage output channel1	B1	U1-	Voltage output channel1
A2	U2+	Voltage output channel2	B2	U2-	Voltage output channel2
A3	U3+	Voltage output channel3	B3	U3-	Voltage output channel3
A4	U4+	Voltage output channel4	B4	U4-	Voltage output channel4
A5	U5+	Voltage output channel5	B5	U5-	Voltage output channel5
A6	U6+	Voltage output channel6	B6	U6-	Voltage output channel6
A7	U7+	Voltage output channel7	B7	U7-	Voltage output channel7
A8	U8+	Voltage output channel8	B8	U8-	Voltage output channel8
A9	24V	24V power input	B9	0V	0V input


4.12.2 Specifications

Structural parameters	
Dimensions (WxHxD)	12mm x 100mm x 80mm
Weight	71.5g
Power Parameters	
The rated voltage of the USYS bus input power supply	5V DC +20%/-15% (4.25V DC~ 6V DC)
The USYS bus input power supply is rated current	<50mA (typical at 5V DC)
UOUT power supply input rated voltage	24 V DC +20%/-15% (20.4V DC~28.8V DC)
UOUT power supply input current rating	<200mA
UOUT power input anti-reverse plug protection	Yes
Functional parameters	
Module type	Analog output
Number of channels	8
Signal type	voltage

Voltage output range	$\pm 10V$ 、 $0\sim 10V$ 、 $2\sim 10V$ 、 $\pm 5V$ 、 $0\sim 5V$ 、 $1\sim 5V$
Voltage output load	$>1k\Omega$
Voltage output accuracy	$\pm 0.1\%$ (Full scale)
Whether to quarantine	The interface channel is not isolated, the interface is isolated from the bus, 500VAC
Drift	$\pm 50ppm/k$
Diagnose and report feature configurations	Yes
Diagnostic tests	Communication diagnostics, power diagnostics
Channel mode settings	Disable、 $\pm 10V$ 、 $0\sim 10V$ 、 $2\sim 10V$ 、 $\pm 5V$ 、 $0\sim 5V$ 、 $1\sim 5V$
Output status configuration after shutdown	Keep the current output or output preset
Stop mode	Press the faildown state mode and no longer refresh
Output action display	When the output is valid, the output Light is on
Software parameters	
Convert the range of digital quantities	$-20000\sim 20000$ 、 $-32000\sim 32000$ 、 $-27648\sim 27648$
IO process data size	16byte
Error diagnosis	Communication diagnostics, power diagnostics
Sync mode	Synchronization within the same coupler group is supported
IO MAPPING	Word-by-word mapping is supported
Wiring parameters	
Connectivity technology	PUSH-IN type terminal blocks
Connection type	System/field power/input
Crimping area of the wire	$0.34\sim 1.5mm$
Stripping length	10mm
Installation method:	DIN-35 TYPE RAIL
Material parameters	
Color	Pantone 419C

Shell material	PC PLASTIC
Environmental requirements	
Allowable ambient temperature (during operation)	-20~55°C
Allowable ambient temperature (storage)	-40~85°C
Types of protection	IP20
Contamination level	2. Comply with IEC 61131-2 standard
Working altitude	0~2000m
Relative humidity (non-condensing)	5~95%RH
Anti-vibration	1g, in accordance with IEC 60068-2-6 standard
Impact resistance	15g, in accordance with IEC 60068-2-27
EMC ANTI-INTERFERENCE RATING	Zone B, IEC61131-2
Corrosion resistance	Compliant with IEC 60068-2-42 and IEC 60068-2-43 standards

4.12.3 Wiring diagram



4.13 DF30-M-4RTD/TC

4.13.1Part description

Light				
4RTD/TC P☐ ☐ R 1☐ 2☐ 3☐ 4☐	LED No	Status and Meaning	LED No	Status and Meaning
	PWR	Green: The system power supply is normal	RUN	Green: The module is running normally
		Green extinguishing: The system power supply is abnormal		Green extinguishing: The system power supply is abnormal
				Green flashing: Configuration failure/failsafe mode
	LED1-4	Green: Channels 1-4 input Signal is valid		
		Green extinguished: Channels 1-4 input signal is invalid		
		Green flashing: When the diagnostic switch for channels 1-4 is turned on, the corresponding channel input fault		

Terminal block					
Serial number	Signal	illustrate	Serial number	Signal	illustrate
A1	RTD1+	The first channel Signal input	B1	RTD1-	The first channel Signal input
A2	Sense1+ (TC+)	The first channel Signal input	B2	Sense1- (TC-)	The first channel Signal input
A3	RTD2+	Second channel Signal input	B3	RTD2-	Second channel Signal input
A4	Sense2+ (TC+)	Second channel Signal input	B4	Sense2- (TC-)	Second channel Signal input
A5	RTD3+	Third channel Signal input	B5	RTD3-	Third channel Signal input
A6	Sense3+ (TC+)	Third channel Signal input	B6	Sense3- (TC-)	Third channel Signal input
A7	RTD4+	Fourth channel Signal input	B7	RTD4-	Fourth channel Signal input
A8	Sense4+ (TC+)	Fourth channel Signal input	B8	Sense4- (TC-)	Fourth channel Signal input
A9	/	Reserve suspension	B9	/	Reserve suspension

4.13.2 Specifications

Structural parameters	
Dimensions (WxHxD)	12mm x 100mm x 80mm
Weight	71.5g
Power Parameters	
The rated voltage of the USYS bus input power supply	5V DC +20%/-15% (4.25V DC~ 6V DC)
The USYS bus input power supply is rated current	<60mA (typical values at 5V DC)
Functional parameters	


Module type	Thermoresistance thermocouple measurement module
Number of channels	4
Sensor type	Pt100, Pt200, Pt500, Pt1000, Ni100, Ni120, Ni200, Ni500, Ni1000, Cu10, Cu50, Cu53, Cu100, KTY83-110, KTY83-120, KTY83-121, KTY83-122, KTY83-150, KTY83-151, KTY84-130, KTY84-150, KTY84-151, 40 Ω , 300 Ω , 500 Ω , 1 k Ω , 2 k Ω , K, E, T, J, B, S, R, N, C, L, $\pm 15.625\text{mV}$, $\pm 31.25\text{mV}$, $\pm 62.5\text{mV}$, $\pm 125\text{mV}$, $\pm 250\text{mV}$, $\pm 500\text{mV}$, $\pm 1000\text{mV}$, $\pm 2000\text{mV}$
Connection	2-wire system, 3-wire system, 4-wire system
Input accuracy (25° C)	Full scale* ($\pm 0.1\%$)
Drift	$\pm 50\text{ppm/K}$, $\pm 0.375\%$
Connection method	Two-wire/three-wire/four-wire system
Whether to quarantine	The interface is isolated from the bus, between the terminal and the power supply, and not between the channels
Channel diagnostics	Over-limit alarm, over-limit alarm, disconnection alarm, overflow error
Diagnose and report feature configurations	Yes
Input action display	When the input signal is valid, the channel input light is solid, and when the channel diagnosis is enabled, the channel input light flashes when the input signal is invalid
Software parameters	
Sampling period	RTD: 250ms/TC: 500ms、RTD: 500ms/TC: 1000ms、RTD: 1000ms/TC: 2000ms、RTD: 320ms/TC: 640ms (50Hz frequency suppression)、RTD: 266ms/TC: 532ms (60Hz frequency suppression)
Filtering method	Sliding window filtering, dejitter filtering, 50HZ\60HZ anti-power frequency
Frequency interference	Yes 50Hz 60Hz restrain

suppression	
Data size	8 Byte
Error diagnosis	Communication diagnosis, power supply diagnosis, channel overrun diagnosis, channel disconnection diagnosis
IO MAPPING	Word-by-word mapping is supported
Wiring parameters	
Connectivity technology	PUSH-IN type terminal blocks
Connection type	System/field power/input
Crimping area of the wire	0.34~1.5mm
Stripping length	10mm
Installation method:	DIN-35 TYPE RAIL
Material parameters	
Color	Pantone 419C
Shell material	PC PLASTIC
Environmental requirements	
Allowable ambient temperature (during operation)	-20~55°C
Allowable ambient temperature (storage)	-40~85°C
Types of protection	IP20
Contamination level	2. Comply with IEC 61131-2 standard
Working altitude	0~2000m
Relative humidity (non-condensing)	5~95%RH
Anti-vibration	1g, in accordance with IEC 60068-2-6 standard
Impact resistance	15g, in accordance with IEC 60068-2-27
EMC ANTI-INTERFERENCE RATING	Zone B, IEC61131-2

Corrosion resistance


Compliant with IEC 60068-2-42 and IEC 60068-2-43 standards

4.13.3 Wiring diagram



4.14 DF30-M-8TC

4.14.1 Part description

Light				
	LED No	Status and Meaning	LED No	Status and Meaning
	PWR	Green: The system power supply is normal	RUN	Green: The module is running normally
		Green extinguishing: The system power supply is abnormal		Green extinguishing: The system power supply is abnormal
				Green flashing: Configuration failure/failsafe mode
	LED1-8	Green light: Channels 1-8 input Signal is valid		
		Green extinguishing: Channels 1-8 input signal is invalid		
		Green flashing: When the input diagnostic switch on channels 1-8 is		

		turned on, the corresponding channel input fault			
Terminal block					
Serial number	Signal	illustrate	Serial number	Signal	illustrate
A1	TC1+	Thermocouple input channel1	B1	TC1-	Thermocouple input channel1
A2	TC2+	Thermocouple input channel2	B2	TC2-	Thermocouple input channel2
A3	TC3+	Thermocouple input channel3	B3	TC3-	Thermocouple input channel3
A4	TC4+	Thermocouple input channel4	B4	TC4-	Thermocouple input channel4
A5	TC5+	Thermocouple input channel5	B5	TC5-	Thermocouple input channel5
A6	TC6+	Thermocouple input channel6	B6	TC6-	Thermocouple input channel6
A7	TC7+	Thermocouple input channel7	B7	TC7-	Thermocouple input channel7
A8	TC8+	Thermocouple input channel8	B8	TC8-	Thermocouple input channel8
A9	\	\	B9	\	\


4.14.2 Specifications

Structural parameters	
Dimensions (WxHxD)	12mm x 100mm x 80mm
Weight	71.5g
Power Parameters	
The rated voltage of the USYS bus input power supply	5V DC +20%/-15% (4.25V DC~ 6V DC)
The USYS bus input power	<60mA

supply is rated current	
Functional parameters	
Module type	Analog input
Number of channels	8
Signal type	thermocouple
Connection type	2-wire system
Display sensitivity	0.1°C
Input terminals	Thermocouple input, thermocouple type: K、E、T、J、B、S、R、N、C、L、 $\pm 15.625\text{mV}$ 、 $\pm 31.25\text{mV}$ 、 $\pm 62.5\text{mV}$ 、 $\pm 125\text{mV}$ 、 $\pm 250\text{mV}$ 、 $\pm 500\text{mV}$ 、 $\pm 1000\text{mV}$ 、 $\pm 2000\text{mV}$
Compensation method	Internal cold end compensation
Accuracy (normal temperature 25° C)	Thermocouple measurement: ($\pm 0.1\%$) ($\pm 125\text{mV}$ full scale) + cold end compensation error Voltage Measurement: ($\pm 0.1\%$) ($\pm 2000\text{mV}$ Full Scale)
Accuracy (Operating Temperature -20° C~55° C)	Thermocouple measurement: ($\pm 0.3\%$) ($\pm 125\text{mV}$ full scale) + cold end compensation error Voltage measurement: ($\pm 0.3\%$) ($\pm 2000\text{mV}$ full scale)
Whether to quarantine	The interface is isolated from the bus, between the terminal and the power supply, and not between the channels
Input action display	When the output is active, the output Light is on (software control)
Software parameters	
Sampling period	500ms、1000ms、2000ms、1280ms (50Hz frequency suppression)、1064ms (60Hz frequency suppression)
Filtering method	Sliding window filtering, dejitter filtering, 50HZ\60HZ anti-power frequency
Data size	16 Byte
Error diagnosis	Communication diagnosis, power supply diagnosis, channel overrun diagnosis, channel disconnection diagnosis


IO MAPPING	Word-by-word mapping is supported
Wiring parameters	
Connectivity technology	PUSH-IN type terminal blocks
Connection type	System/field power/input
Crimping area of the wire	0.34~1.5mm
Stripping length	10mm
Installation method:	DIN-35 TYPE RAIL
Material parameters	
Color	Pantone 419C
Shell material	PC PLASTIC
Environmental requirements	
Allowable ambient temperature (during operation)	-20~55°C
Allowable ambient temperature (storage)	-40~85°C
Types of protection	IP20
Contamination level	2. Comply with IEC 61131-2 standard
Working altitude	0~2000m
Relative humidity (non-condensing)	5~95%RH
Anti-vibration	1g, in accordance with IEC 60068-2-6 standard
Impact resistance	15g, in accordance with IEC 60068-2-27
EMC ANTI-INTERFERENCE RATING	Zone B, IEC61131-2
Corrosion resistance	Compliant with IEC 60068-2-42 and IEC 60068-2-43 standards

4.14.3 Wiring diagram



4.15 DF30-M-2CNT

4.15.1Part description

Light				
	LED No	Status and Meaning	LED No	Status and Meaning
	PWR	Green: The system power supply is normal	RUN	Green: The module is running normally
		Green extinguishing: The system power supply is abnormal		Green extinguishing: The system power supply is abnormal
				Green flashing: Configuration failure/failsafe mode
	1A/1B/2A	Green Light: 1A/1B/2A/2B differential signal input indicates, input is the driving state		
	/2B	Green extinguishing: 1A/1B/2A/2B differential signal input indication, the input is not in the driving state		

	DI1/DI2/ DI3/DI4	Green Bright: DI1/DI2/DI3/DI4 Digital input channel indicator, input is the drive status.			
		Green off: DI1/DI2/DI3/DI4 Digital input channel indicator, input is not in driving state.			
	DO1/DO2	Green Light: DO1/DO2 Digital output channel indication, output is in driving state.			
		Green Light: DO1/DO2 Digital output channel indication, output is in driving state.			
Terminal block					
Serial number	Signal	illustrate	Serial number	Signal	illustrate
A1	5V	The 5V power supply outputs the positive electrode	B1	AGND	5V power supply output negative electrode
A2	1A+	Channel 1A is a differential input Signal+	B2	1A-	Channel 1A Phase-Differential Input Signal-
A3	1B+	Channel 1B phase-differential input Signal+	B3	1B-	Channel 1B is a phase-differential input signal-
A4	2A+	Channel 2A is a differential input Signal+	B4	2A-	Channel 2A Phase Difference Input Signal-
A5	2B+	Channel 2B is a phase-differential input Signal+	B5	2B-	Channel 2B Phase-Differential Input Signal-
A6	DI 1	Digital input channel1	B6	DI 2	Digital input channel2
A7	DI 3	Digital input channel3	B7	DI 4	Digital input channel4
A8	COM	Public end	B8	PE	ground

A9	D0 1	Digital output channel1	B9	D0 2	Digital output channel2
----	------	-------------------------	----	------	-------------------------


4.15.2 Specifications

Structural parameters	
Dimensions (WxHxD)	12mm x 100mm x 80mm
Weight	71.5g
Power Parameters	
The rated voltage of the USYS bus input power supply	5V DC +20%/-15% (4.25V DC~ 6V DC)
The USYS bus input power supply is rated current	<50mA (Typical at 5V DC)
The terminal output power supply is rated voltage	5V DC
The module prevents the spread of power failures	Yes
Functional parameters	
Differential counting input specifications	
Module type	Counter inputs (single-phase pulse plus directional, A-phase, B-phase, AB-phase, SSI)
Input method	Differential input
Number of channels	2
Differential input voltage level	RS422 level (logic 0<200 mA; Logic 1 >200 mA)
Highest input frequency	4Mhz
Count range	32 位
Frequency measurement range	0.04HZ~4Mhz
Counting accuracy	100ppm
Whether to quarantine	Yes
Input action display	When the input is in the drive state, the input Light is on (hardware control)


Single-ended input specifications	
Input type	Numeric input
Input method	Single-ended input, NPN/PNP
Enter the channel	4 (Counting channels are 2 channels, AB phase per channel)
Frequency measurement range	0.04Hz~500kHz
Input voltage level	24V DC (20.4V DC~28.8V DC)
Input Current (Typical)	50 mA (24V typical)
ON voltage	>15V DC
OFF voltage	<5V DC
Whether to quarantine	Yes
Input action display	When input is in the drive state, input Light (hardware control)
Output specifications	
Output type	Digital output
Output method	NPN
Output channel	2
Output voltage level	24V DC (20.4V DC ~28.8V DC)
Output Load (Resistive Load)	0.5A/point, 1A/module
Output Load (Inductive Load)	7.2W/点, 1A/模块
Output load (light load)	10W/模块 5W/point, 10W/module
Output action display	When the output is in the drive state, the input Light is on (hardware control)
Software parameters	
Data size	72 Byte
Error diagnosis	Communication diagnosis and configuration parameter diagnosis
Communication Fault Count status mode	Keep the current count value, clear the count value, and continue counting
Communication fault output	Turn off the output, enable the output, and keep the current

state mode	output
IO MAPPING	Support bit-by-bit, byte-by-byte, and word-by-word mapping
Wiring parameters	
Connectivity technology	PUSH-IN type terminal blocks
Connection type	System/field power/input
Crimping area of the wire	0.34~1.5mm
Stripping length	10mm
Installation method:	DIN-35 TYPE RAIL
Material parameters	
Color	Pantone 419C
Shell material	PC PLASTIC
Environmental requirements	
Allowable ambient temperature (during operation)	-20~55°C
Allowable ambient temperature (storage)	-40~85°C
Types of protection	IP20
Contamination level	2. Comply with IEC 61131-2 standard
Working altitude	0~2000m
Relative humidity (non-condensing)	5~95%RH
Anti-vibration	1g, in accordance with IEC 60068-2-6 standard
Impact resistance	15g, in accordance with IEC 60068-2-27
EMC ANTI-INTERFERENCE RATING	Zone B, IEC61131-2
Corrosion resistance	Compliant with IEC 60068-2-42 and IEC 60068-2-43 standards

4.15.3 Wiring diagram



- Suitable for differential encoders that output 422 level characteristics, the differential encoder electrical Wiring diagram is shown in the figure below.




The module supports the connection of two differential encoders: 1A and 1B as a group, and 2A and 2B as a group (the figure shows that 1A and 1B are connected as a group of connections as an example, and if you need to connect a group of 2A and 2B, the connection method is the same.)

The module supports up to 4 DI digital inputs: DI1、DI2、DI3、DI4 (for example, if you need to connect DI2, DI3, or DI4, the connection method is the same.

The module supports connecting up to two DO digital outputs: DO1 and DO2 (the figure shows DO1 as an example, if you need to connect DO2, the connection method is the same.)


- The single-ended encoder of the NPN type is suitable for collector output transistors, and the electrical wiring diagram (NPN type) of the single-ended encoder is shown in the figure below.



The module supports connecting up to two single-ended encoders: DI1 and DI2 as a group, DI3 and DI4 as a group (the figure shows that DI1 and DI2 are connected as a set of connections as an example, and if you need to connect a group of DI3 and DI4, the connection method is the same.)

The module supports the connection of two D0 digital outputs: D01 and D02 (the figure shows D01 as an example, if D02 needs to be connected, the connection method is the same.)


- The single-ended encoder of the PNP type is suitable for collector output transistors, and the electrical wiring diagram (NPN type) of the single-ended encoder is shown in the figure below.



The module supports connecting up to two single-ended encoders: DI1 and DI2 as a group, DI3 and DI4 as a group (the figure shows that DI1 and DI2 are connected as a set of connections as an example, and if you need to connect a group of DI3 and DI4, the connection method is the same.)

The module supports connecting up to two DO digital outputs: DO1 and DO2 (the figure shows DO1 as an example, if you need to connect DO2, the connection method is the same.))

- The electrical wiring diagram of the encoder for SSI and Tama River encoders is shown in the figure below:



The module supports the connection of up to 2 SSI encoders/Tama River encoders: 1A and 1B as a group, and 2A and 2B as a group. (The figure shows that 1A and 1B are used as a group of connections as an example, and if you need to connect a group of 2A and 2B, the connection method is the same.)

Notes: :

- DF30-M-2CNT The module supports the connection of up to 2 differential encoders: 1A and 1B for channel 1, and 2A and 2B for channel 2.
- DF30-M-2CNT The module supports the connection of up to 2 SSI encoders/Tama River encoders: 1A and 1B for channel 1, and 2A and 2B for channel 2.
- DF30-M-2CNT The module supports up to 4 DI digital inputs: DI1、DI2、DI3、DI4。
- DF30-M-2CNT The module supports up to 2 DO digital outputs: DO1 和 DO2
- DF30-M-2CNT When channel 1 is selected as a single-termination method, DI1 and DI2 correspond to the AB phase of channel 1, and when channel 2 is selected as a single-termination method, DI3 and DI4 correspond to the AB phase of channel 2 respectively.

4.16 DF30-M-1COM-232/485/422
4.16.1 Part description

Light				
	LED No	Status and Meaning	LED No	Status and Meaning
1COM ☐ F ☐ R ☐ TX ☐ COM ☐ RX ☐ MST ☐ SLV ☐ 232 ☐ 485 ☐ 422	PWR	Green: The system power supply is normal	RUN	Green: The module is running normally
		Green extinguishing: The system power supply is abnormal		Green extinguishing: The system power supply is abnormal
				Green flashing: Configuration failure/failsafe mode
	TX	Green: Data sent	COM	Green Light: Select this mode
		Green extinguishing: No data transmission		Green extinguishing: This mode is not used
	RX	Green light: Data reception	MST	Green Light: Select MASTER mode
		Green extinguishing: No data reception		Green extinguishing: This mode is not used
			SLV	Green: Select SLAVE mode
				Green extinguishing: This mode is not used
			232	Green light: RS232 communication protocol is used
				Green extinguishing: This communication protocol is not used
			485	Green light: RS485 communication protocol is used

				Green extinguishing: This communication protocol is not used	
			422	Green light: RS422 communication protocol is used	
				Green extinguishing: This communication protocol is not used	
Terminal block					
Serial number	Signal	illustrate	Serial number	Signal	illustrate
A1	24Vo	24V power output	B1	0Vo	Power output location
A2	5Vo	5V power output	B2	0Vo	Power output location
A3	TXD+	RS485 data positive end/RS422 transmitting positive end	B3	TXD-	RS485 data negative end/RS422 send negative end
A4	Tres+	RS485 terminal resistor positive/RS422 transmit terminal resistor positive	B4	Tres-	RS485 terminal resistor negative / RS422 transmit terminal resistor negative end
A5	RXD+	RS422 receives positive end	B5	RXD-	RS422 receives negative end
A6	Rres+	RS422 receiver terminal resistor positive end	B6	Rres-	The RS422 receiver terminal resistor is negative
A7	CTS	RS232 clear send	B7	RTS	RS232 sends data requests
A8	RXD	RS232 data reception	B8	TXD	RS232 data transmission
A9	GND	Reference Location	B9	GND	Reference Location

4.16.1 Specifications


Structural parameters	
Dimensions (WxHxD)	12mm x 100mm x 80mm
Weight	71.5g
Power Parameters	
The rated voltage of the USYS bus input power supply	5V DC +20%/-15% (4.25V DC~ 6V DC)
The USYS bus input power supply is rated current	<60mA (typical at 5V DC)
UIN power supply input rated voltage	24 V DC +20%/-15% (20.4V DC~28.8V DC)
UIN power supply input current rating	60mA (typical at 5V DC)
UIN power input anti-reverse plug protection	Yes
The module prevents the spread of power failures	Yes
Functional parameters	
Module type	Communication gateway module
Number of channels	1 way
Communication interface type	The module only communicates with the Yes1 serial port 1 RS232 1 RS485 1 RS422
Communication distance	RS232: up to 15m RS422/RS485: Max. 1200m
Whether to quarantine	Yes, the channels are isolated from the interior, and the channels are not isolated
Terminal matching resistors	Short connection at the near end of the terminal resistor port through the user's external wiring selection

Output load	Voltage standard value 24V, maximum current: 200mA; Voltage standard value 5V, maximum current: 500mA Two output loads can be output simultaneously
Software parameters	
Data size	A maximum of 128 bytes per channel
Error diagnosis	Take the initiative to report
Number of modules supported	A single coupler can mount up to 6 modules
Number of channels	Up to 18 channels Yes
Modbus protocol	RTU
Data transmission baud rate	1200 bps~4687500 bps (Default 9600 bps)
Working mode	Modbus Master/Modbus Slave/Free Transmission (Default Modbus Master)
Communication interface	RS485/RS232/RS422 (default RS485)
Data bits	7-bit/8-bit (default 8-bit needs to be checked when configured as 7-bit)
Check position	No check/odd/even check
starting position	1st place
stop position	1-bit, 2-bit (default 1-bit)
Frame interval time	The interval between receiving the slave response and sending it again in master mode is 0~65535, in ms.
Response timeout	The master waits for the timeout time for the slave station to respond, or the timeout time for the response in transparent mode.
Polling time	The delay between when the master receives the response message from the slave to the next command is sent in the range 0~65535, in ms.
Read timeout	Keep last input/clear input value
Data output mode	Polling mode/event triggering/level triggering/rising edge triggering. (Event trigger is data output when the

	output data changes, and level trigger is the main station channel control word is 1.)Trigger communication, and the rising edge triggers the communication when the main station channel control word is from 0 to 1)
Slave Station ID	The module works in the ID number of the slave.
Response delay	The working mode is to receive a message from the master station when the slave station is received, and the delay response is made to the master station and the unit ms.
Byte order conversion	The working mode is to exchange every two transmitting and receiving data positions during free transmission.
Wiring parameters	
Connectivity technology	PUSH-IN type terminal blocks
Connection type	System/field power/input
Crimping area of the wire	0.34~1.5mm
Stripping length	10mm
Installation method:	DIN-35 TYPE RAIL
Material parameters	
Color	Pantone 419C
Shell material	PC PLASTIC
Environmental requirements	
Allowable ambient temperature (during operation)	-20~55°C
Allowable ambient temperature (storage)	-40~85°C
Types of protection	IP20
Contamination level	2. Comply with IEC 61131-2 standard
Working altitude	0~2000m
Relative humidity	5~95%RH

(non-condensing)	
Anti-vibration	1g, in accordance with IEC 60068-2-6 standard
Impact resistance	15g, in accordance with IEC 60068-2-27
EMC ANTI-INTERFERENCE RATING	Zone B, IEC61131-2
Corrosion resistance	Compliant with IEC 60068-2-42 and IEC 60068-2-43 standards

4.16.1 Wiring diagram




5 Configuration example

5.1 CODESYS V3.5.19 software example

In this chapter, CODESYS V3.5 SP19 is used as the configuration software to introduce the use of the adapter DF30-C-MD-TCP, with the DFC501 controller as the Modbus TCP master and the DF30-C-MD-TCP as the Modbus TCP slave DF30-M-16DI-P/N as a remote IO module.


■ Use DFC501 controller as Modbus TCP master

Right-click on the item and click Add Device, select the supplier Hangzhou Liwei Technology Co. LTD, find the Modbus TCP master and double-click Add:



■ Add Modbus TCP device


Right-click Modbus_TCP_Master Add Device (Modbus TCP Master), find the Modbus TCP device, and double-click Add:




Set the Modbus TCP slave IP

Double-click `Modbus_TCP_Device` to set the Modbus TCP device IP to the adapter IP to ensure that the Modbus slave IP, Modbus master IP, and PC local network IP are in the same network segment. The adapter IP is set to 192.168 in advance 1.254. For how to modify the adapter IP, refer to the Coupler IP Address Setting section in [CODESYS V3.5.19 Software Examples](#).


Modbus Master IP Settings:



Modbus slave IP settings:



IP settings for the local network on the PC side:



常规

如果网络支持此功能，则可以获取自动指派的 IP 设置。否则，你需要从网络系统管理员处获得适当的 IP 设置。

☐ 自动获得 IP 地址(O)

☒ 使用下面的 IP 地址(S):

IP 地址(I): 192 . 168 . 1 . 25

子网掩码(U): 255 . 255 . 255 . 0

默认网关(D): 192 . 168 . 1 . 1

☐ 自动获得 DNS 服务器地址(B)

☒ 使用下面的 DNS 服务器地址(E):

首选 DNS 服务器(P): . . .

备用 DNS 服务器(A): . . .

☐ 退出时验证设置(L)

高级(V)...

■ Modbus TCP Slave channel added

Go to the slave channel configuration screen and click Add Remote IO:D F30-M-16DI-P/N



Take the topology of DF30-C-MD-TCP+DF30-M-16DI-P/N as an example: add the first channel to modify the channel name to DF30-M-16DI-P/N, configure the function code operation as a read-hold register, and Modbus HOLD register address: the offset is 656 (decimal, starting from 0)., corresponding PLC address: numbered from 40001, the process data of DF30-M-16DI-P/N is mapped to PLC address 40657, the data size is 2 bytes, the register address of the remote IO and the PCL address mapping relationship refer to [the register address mapping illustrate](#)




Modbus通道配置窗口，包含以下配置项：

- 通道名称: C8EOI16DI
- 访问类型: Read Holding Registers (函数代码 3)
- 触发器: 循环
- 周期时间(ms): 100
- 注释: (空)
- 读寄存器:
 - 偏移: 656
 - 长度: 1
 - 错误处理: 保持最后值
- 写寄存器:
 - 偏移: 0x0000
 - 长度: 1

底部按钮: 确定(O), 取消(C)

Log in to download

Click Login and download the configuration to the controller, click Start after the download is completed, you can see that the RUN light of the adapter is always on, and the software icons are green without error, indicating that the connection has been successfully established.




软件界面截图，显示设备连接状态。顶部菜单栏包含：文件、编辑、视图、工程、编译、在线、调试、工具、窗口、帮助。中间部分显示设备树，包括：Device (SMC501)、PLC逻辑、LocalBus (LocalBus)、Modbus_TCP_Master (Modbus TCP 主站)、Modbus_TCP_Device (Modbus TCP 设备)、SoftMotion General Axis Pool。右侧显示变量映射表，包含：变量、映射、通道、地址、类型、单元、描述。底部显示设备连接状态，标注为“正常连接”。

变量	映射	通道	地址	类型	单元	描述
Slave Disable			%QX0.0	BOOL		
Connected			%IX0.0	BOOL		
Channel Disable			%QW1	WORD		
Channel State			%IW1	ARRAY [0..9] OF CHANNEL_STATE		
ER20-16DI			%IW31	ARRAY [0..0] OF WORD		Read ...

底部显示设备连接状态，标注为“正常连接”。

Once all channels have been added, they need to be downloaded back to the controller

Go to the I/O mapping interface and change the Always Update variable to Enable 1



■ Web page configuration function

IP address configuration:

- Configure the adapter IP via the web page or DIP switch, Yes reset to the default address (192.168.1.254)。
- Modbus the operation priority of the configuration is greater than that of the web page configuration, and the operation of the Mosbus configuration must be stopped before using the web page to manage and configure the Modbus TCP adapter, for example, the operation of the Modbus configuration must be stopped when the Modbus Poll software is disconnected or the Modbus Poll software is closed.

Module parameter configuration:

- Channel filtering time (digital amount), Signal range (analog), sensor type (thermoresistor/thermocouple), etc.
- Operation process: Log in to the adapter web interface, select the module location, set the parameters, save and restart to take effect.

■ Coupler IP address configuration

IP address setting: When the IP address of the adapter is lost, forgotten, or other abnormal situations, dial the DIP switch to 254 and restart the adapter, and the IP address of the resettable adapter is 192.168.1.254

Web page configuration IP

- Operation process: Dial the DIP switch to 0 or 255, restart the adapter, wait for the module initialization to complete (3~5s), log in to the adapter web interface, and the user modifies the network information of the adapter: MAC address (read-only), IP address (read-write), subnet mask (read-write), click the save button, and wait for 10s to automatically jump to a new web page (premise:). The network information of the newly configured adapter is in the same

network segment as the current configured PC, if it is not in the same CIDR segment, the CIDR segment of the configured PC needs to be reset).

Network Settings

MAC Address 02:DB:64:A7:1C:52	IP Address 192.168.1.254
Subnet Mask 255.255.255.0	Gateway 192.168.1.1

Save Configuration

Firmware Info: Name: Modbus Controller Version: V1.0

DIP switch configuration IP

- The DIP switch can be used to set the last byte of the adapter's IP address, i.e. the D byte of the IP address A:B:C:D, and the IP ground

The A/B/C bytes of the address can only be modified through the web page, and the restart takes effect.

- When the DIP switch is dialed to 0 or 255, the adapter IP address adopts the IP configured on the web page. When the dial value is greater than 0 and less than 254. At this time, the last byte D of the adapter's IP is the current dial value, and the first three bytes are the A/B/C of the web page configuration, and the restart takes effect. When the DIP switch is set to 254, it can be reset to the default address (192.168.1.254) and the restart takes effect.

Network Settings

MAC Address 02:DB:64:A7:1C:52	IP Address 192.168.1.254
Subnet Mask 255.255.255.0	Gateway 192.168.1.1

Save Configuration

Firmware Info: Name: Modbus Controller Version: V1.0

■ Remote IO module parameter configuration

■ Example:

Log in to the adapter web interface, select the DF30-M-16DI-P/N module location, enter the DI module configuration interface, set the filtering parameters of each channel and save it to take

effect, and click Back to return to the main interface for the next valid module configuration

I/O Modules 有效模块

DF30-M-16DI-P/N No. 1	NONE_MOD No. 2	NONE_MOD No. 3	NONE_MOD No. 4
NONE_MOD No. 5	NONE_MOD No. 6	NONE_MOD No. 7	NONE_MOD No. 8
NONE_MOD No. 9	NONE_MOD No. 10	NONE_MOD No. 11	NONE_MOD No. 12

DI Config

Module Type: 模块型号
 DF30-M-16DI-P/N

Module Number: 模块的拓扑序列号
 1

Firmware Version:
 V2.0.2

模块固件版本号

Register Mapping 模块过程数据在PCL中寄存器地址映射

Holding Registers:
 40657

Discrete Inputs:
 10001-10016

Channel Configuration

DI CH1
 Filter Time: 可配置参数
 3
 Save CH1

DI CH2
 Filter Time:
 3
 Save CH2

DI CH3
 Filter Time:
 3
 Save CH3

DI CH4
 Filter Time:
 3
 Save CH4

DI CH5
 Filter Time:
 3
 Save CH5

DI CH6
 Filter Time:
 3
 Save CH6

DI CH7
 Filter Time:
 3
 Save CH7

DI CH8
 Filter Time:
 3
 Save CH8

DI CH9 Filter Time: 3 Save CH9	DI CH10 Filter Time: 3 Save CH10	DI CH11 Filter Time: 3 Save CH11	DI CH12 Filter Time: 3 Save CH12
DI CH13 Filter Time: 3 Save CH13	DI CH14 Filter Time: 3 Save CH14	DI CH15 Filter Time: 3 Save CH15	DI CH16 Filter Time: 3 Save CH16

■ Invalid module display:

Module Not Detected

The system could not detect a valid hardware module.
Please ensure the module is properly connected and try again.

Troubleshooting Steps:


- ★ Check physical connections
- ★ Verify module compatibility
- ★ Restart the device
- ★ Consult documentation

■ Process data mapping

Example of the topology of DF30-C-MD-TCP+DF30-M-16DI-P/N:

Add the first channel to modify the channel name as DF30-M-16DI-P/N-Read-hold: Configure function code operation as read-hold register, Modbus HOLD register address: offset is 656 (decimal, from 0), length 1, corresponding PLC address: number from 40001, DF30-M-16DI-P/ N's process data is mapped at PLC address 40657, and the data occupies 1 hold register;

Or add channel DF30-M-16DI-P/N-Read discrete input: configure function code operation to read discrete input registers, Modbus Discrete input register address: offset address 0 (decimal, starting from 0), length 16, corresponding PLC address: numbering from 10001, DF30-M-16DI-P/ N process data mapping at PLC address 10001-10016; For the relationship between the register address and the PCL address mapping of the remote IO, refer to [the register address mapping illustrate](#)



DI Config

Module Type: Module Number:

Firmware Version:

Register Mapping

Holding Registers: Discrete Inputs:

RXPDO				
Serial number	Type of information	Register address	data format	remark
1	Hold registers:	40657	UINT16	(Read Operation).
2	Discrete Input Registers:	10001-10016	BIT (Discrete)	(Read Operation).

The effective voltage of channel 1 input of the DF30-M-16DI-P/N is 24V, and the process data shows that the hold register: 0x0001, and the discrete data register bit0=1

通用	查找	过滤器	显示所有	中 为IO通道添加FB...	转到实例				
Modbus从站通道	变量	映射	通道	地址	类型	当前值	预备值	单元	描述
Modbus从站初始化	 		16DI-读保持	%IW0	ARRAY [0..0] OF WORD	仅更新子元素			Read Holding Registers
	 		16DI-读保持[0]	%IW0	WORD	16#0001			0x0290
ModbusTCPSlave参数	 		16DI-读离散	%IB2	ARRAY [0..1] OF BYTE	仅更新子元素			Read Discrete Inputs
	 		16DI-读离散[0]	%IB2	BYTE	16#01			Read Discrete Inputs
ModbusTCPSlaveIO映射	 		Bit0	%IX2.0	BOOL	TRUE			0x0000
	 		Bit1	%IX2.1	BOOL	FALSE			0x0001
	 		Bit2	%IX2.2	BOOL	FALSE			0x0002
	 		Bit3	%IX2.3	BOOL	FALSE			0x0003
	 		Bit4	%IX2.4	BOOL	FALSE			0x0004
	 		Bit5	%IX2.5	BOOL	FALSE			0x0005
	 		Bit6	%IX2.6	BOOL	FALSE			0x0006
	 		Bit7	%IX2.7	BOOL	FALSE			0x0007
ModbusTCPSlaveIO对象	 		16DI-读离散[1]	%IB3	BYTE	16#00			Read Discrete Inputs
状态									
信息									

The effective voltage of channel 16 input of the DF30-M-16DI-P/N is 24V, and the process data shows that the holding register: 0x8000, and the discrete data register BYTE[1]=0x80

通用	查找	过滤器	显示所有	为IO通道添加FB...		转到实例			
	变量	映射	通道	地址	类型	当前值	预置值	单元	描述
Modbus从站通道			16DI-读保持	%IW0	ARRAY [0..0] OF WORD	仅更新子元素			Read Holding Registers
Modbus从站初始化			16DI-读保持[0]	%IW0	WORD	16#8000		0x290	
ModbusTCPSlave参数			16DI-读离散	%IB2	ARRAY [0..1] OF BYTE	仅更新子元素			Read Discrete Inputs
ModbusTCPSlaveIO映射			16DI-读离散[0]	%IB2	BYTE	16#00			Read Discrete Inputs
			16DI-读离散[1]	%IB3	BYTE	16#80			Read Discrete Inputs
ModbusTCPSlaveI/O对象			Bit0	%IX3.0	BOOL	FALSE		0x0008	
			Bit1	%IX3.1	BOOL	FALSE		0x0009	
			Bit2	%IX3.2	BOOL	FALSE		0x000A	
			Bit3	%IX3.3	BOOL	FALSE		0x000B	
			Bit4	%IX3.4	BOOL	FALSE		0x000C	
			Bit5	%IX3.5	BOOL	FALSE		0x000D	
			Bit6	%IX3.6	BOOL	FALSE		0x000E	
状态			Bit7	%IX3.7	BOOL	TRUE		0x000F	
信息									

■ Coupler firmware version query

Way 1

Log in to the configuration page and view the adapter firmware version number on the homepage:

Network Settings

MAC Address

02:DB:64:A7:1C:52

IP Address

192.168.1.254

Subnet Mask

255.255.255.0

Gateway

192.168.1.1

Save Configuration

Firmware Info:


Name: Modbus Controller

Version: V1.0

Way 2

Serial number	Type of information	Register address	data format	remark
1	Hold registers:	40002	UINT16	(Read Operation).

Add channel system diagnostics - coupler firmware version: read-hold register, address offset 1, length 1:



Modbus通道配置窗口，显示了系统诊断-耦合器固件版本的配置。配置项包括：名称（系统诊断-耦合器固件版本）、访问类型（Read Holding Registers (函数代码 3)）、触发器（循环）、周期时间（ms）（100）、注释、读寄存器偏移（0x0001）、长度（1）、错误处理（保持最后值）、写寄存器偏移（0x0000）、长度（0）。底部有确定(O)和取消(C)按钮。

Note: The firmware version number is decimal value of 16#0100, which means that the version number is V1.0.0.

通用	查找	过滤器	显示所有	地址	类型	当前值	预备值	单元	描述
Modbus从站通道	变量	映射	通道	地址	类型	当前值	预备值	单元	描述
Modbus从站初始化	ER20-16DI-读保持		%IW0	ARRAY [0..0] OF WORD	仅更新子元素				Read Holding Registers
ModbusTCPSlave参数	ER20-16DI-读离散		%IB2	ARRAY [0..1] OF BYTE	仅更新子元素				Read Discrete Inputs
ModbusTCPSlaveIO映射	系统诊断-耦合器模块计数		%IW2	ARRAY [0..0] OF WORD	仅更新子元素				Read Holding Registers
ModbusTCPSlaveEC对象	系统诊断-耦合器模块计数[0]		%IW2	WORD	16#0001				0x0000
状态	系统诊断-耦合器固件版本		%IW3	ARRAY [0..0] OF WORD	仅更新子元素				Read Holding Registers
信息	系统诊断-耦合器固件版本[0]		%IW3	WORD	16#0100				0x0001
	系统诊断-耦合器故障代码		%IW4	ARRAY [0..0] OF WORD	仅更新子元素				Read Holding Registers
	系统诊断-耦合器故障代码[0]		%IW4	WORD	16#0000				0x0002
	系统诊断-模块ID		%IW5	ARRAY [0..0] OF WORD	仅更新子元素				Read Holding Registers
	系统诊断-模块固件版本		%IW6	ARRAY [0..0] OF WORD	仅更新子元素				Read Holding Registers
	系统诊断-模块故障信息		%IW7	ARRAY [0..0] OF WORD	仅更新子元素				Read Holding Registers
	系统诊断-模块丢包次数		%IW8	ARRAY [0..1] OF WORD	仅更新子元素				Read Holding Registers
	系统诊断-Modbus长连接时间		%IW10	ARRAY [0..1] OF WORD	仅更新子元素				Read Holding Registers

■ Module information query

Example of the topology of DF30-C-MD-TCP+DF30-M-16DI-P/N:

The module firmware version can also be queried via the web interface:

DI Config

Module Type:
DF30-M-16DI-P/N

Module Number:
1

Firmware Version:
V2.0.2

Register Mapping

Holding Registers:
40657

Discrete Inputs:
10001-10016

The module firmware version is queried by configuration addressing: The firmware version number is 16#0202, indicating that the version number is V2.0.2:

Serial number	Type of information	Register address area	data format	remark
1	Module ID[0]	40004	UINT16	0x11
2	Module firmware version[0]	40036	UINT16	Version number of DF30-M-16DI-P/N (HEX: high 8 bits = main version, low 8 bits = secondary version).

变量	映射	通道	地址	类型	当前值	预备值	单元	描述
16DI-读保持		%IW0	ARRAY [0..0] OF WORD	仅更新子元素				Read Holding Registers
16DI-读保持[0]		%IW0	WORD	16#8000				0x0290
系统诊断-耦合器模块计数		%IW1	ARRAY [0..0] OF WORD	仅更新子元素				Read Holding Registers
系统诊断-耦合器模块计数[0]		%IW1	WORD	16#0001				0x0000
系统诊断-耦合器固件版本		%IW2	ARRAY [0..0] OF WORD	仅更新子元素				Read Holding Registers
系统诊断-耦合器固件版本[0]		%IW2	WORD	16#0100				0x0001
系统诊断-耦合器故障代码		%IW3	ARRAY [0..0] OF WORD	仅更新子元素				Read Holding Registers
系统诊断-耦合器故障代码[0]		%IW3	WORD	16#0000				0x0002
系统诊断-模块ID		%IW4	ARRAY [0..0] OF WORD	仅更新子元素				Read Holding Registers
系统诊断-模块ID[0]		%IW4	WORD	16#0011				0x0003
系统诊断-模块固件版本		%IW5	ARRAY [0..0] OF WORD	仅更新子元素				Read Holding Registers
系统诊断-模块固件版本[0]		%IW5	WORD	16#0202				0x0023
系统诊断-模块故障信息		%IW6	ARRAY [0..0] OF WORD	仅更新子元素				Read Holding Registers
系统诊断-模块故障信息[0]		%IW6	WORD	16#0000				0x0043
系统诊断-模块丢包次数		%IW7	ARRAY [0..1] OF WORD	仅更新子元素				Read Holding Registers
系统诊断-模块丢包次数[0]		%IW7	WORD	16#0000				0x0063
系统诊断-模块丢包次数[1]		%IW8	WORD	16#0000				0x0064
系统诊断-Modbus长连接时间		%IW9	ARRAY [0..1] OF WORD	仅更新子元素				Read Holding Registers

■ Module diagnostics

Example of the topology of DF30-C-MD-TCP+DF30-M-16DI-P/N:

Serial number	Type of information	Register address area	data format	remark
1	Module Fault Information [0]	40068	UINT16	(If high 8 bits = 0, then low 8 bits = module fault code: refer to fault code illustrate). (If the high 8 bits = 1~8, the low 8 bits = channel fault code: refer to the fault code illustrate).
2	Module Packet Loss Count [0-1]	40100~40101	UINT32	DF30-M-16DI-P/N Packet Loss Times (Double Word Address) (High 16 bit + low 16 bit combination)

通用	查找	过滤器	显示所有	为IO通道添加FB... 转到实例					
	变量	映射	通道	地址	类型	当前值	预估值	单元	描述
Modbus从站通道	 		16DI-读保持	%IW0	ARRAY [0..0] OF WORD	仅更新子元素			Read Holding Registers
			16DI-读保持[0]	%IW0	WORD	16#8000			0x0290
Modbus从站初始化	 		系统诊断-耦合器模块计数	%IW1	ARRAY [0..0] OF WORD	仅更新子元素			Read Holding Registers
			系统诊断-耦合器模块计数[0]	%IW1	WORD	16#0001			0x0000
ModbusTCPSlave参数	 		系统诊断-耦合器固件版本	%IW2	ARRAY [0..0] OF WORD	仅更新子元素			Read Holding Registers
			系统诊断-耦合器固件版本[0]	%IW2	WORD	16#0100			0x0001
ModbusTCPSlaveIO映射	 		系统诊断-耦合器故障代码	%IW3	ARRAY [0..0] OF WORD	仅更新子元素			Read Holding Registers
			系统诊断-耦合器故障代码[0]	%IW3	WORD	16#0000			0x0002
ModbusTCPSlaveEC对象	 		系统诊断-模块ID	%IW4	ARRAY [0..0] OF WORD	仅更新子元素			Read Holding Registers
			系统诊断-模块ID[0]	%IW4	WORD	16#0011			0x0003
状态	 		系统诊断-模块固件版本	%IW5	ARRAY [0..0] OF WORD	仅更新子元素			Read Holding Registers
			系统诊断-模块固件版本[0]	%IW5	WORD	16#0202			0x0023
信息	 		系统诊断-模块故障信息	%IW6	ARRAY [0..0] OF WORD	仅更新子元素			Read Holding Registers
			系统诊断-模块故障信息[0]	%IW6	WORD	16#0000			0x0043
			系统诊断-模块丢包次数	%IW7	ARRAY [0..1] OF WORD	仅更新子元素			Read Holding Registers
			系统诊断-模块丢包次数[0]	%IW7	WORD	16#0000			0x0063
			系统诊断-模块丢包次数[1]	%IW8	WORD	16#0000			0x0064
			系统诊断-Modbus长连接时间	%IW9	ARRAY [0..1] OF WORD	仅更新子元素			Read Holding Registers

6. appendix

5.2 Trouble code description

Fault location	Fault name	Trouble code	Solution/Cause
Coupler	The protocol stack is not scanned to the module	1	Check whether the module is tightly plugged in and whether the buckle is fastened
	The number of modules is exceeded	2	Check the number of backplane modules
	The configuration IO module does not match the card that is actually scanned	3	Check whether the configuration module model and sequence are consistent with the actual module
	The configuration configuration list is not downloaded	4	
	Hot-swap failed, and the module model was wrong	5	Check whether the newly plugged module Signal is the same as the original
module	The backplane bus timed out	1	Check that the module is installed in place
	Flash read failure	3	Power back or contact the vendor
	Wrong configuration parameters	4	Check whether the configuration parameters are reasonable
	Abnormal power supply	5	Check the power supply
	ADC abnormalities	6	Power back or contact the

			vendor
	DAC abnormalities	7	Power back or contact the vendor
passage	Overcurrent	1	Check if the load is too large
	Overheating	2	Check the external wiring and whether the load is too large
	short circuit	3	Check the external wiring of the channel
	Open circuit/disconnection	4	Check the external wiring of the channel
	Overflow	5	Check if the external input signal is normal
	underflow	6	Check if the external input signal is normal
	Hyper Limit	7	Check if the external input signal is normal
	Exceeding the lower limit	8	Check if the external input signal is normal
	Wrong sensor type	9	Check whether the access sensor and the configuration item match